


**Operating Instructions**

**Acculab Exceleron Series**

ECL Models



# Intended Use

Exceleron is a rugged, easy-to-use electronic scale for the complex quality control tasks you perform every day.

- In the food industry
- In the pharmaceutical industry
- In the chemical industry
- In the textile industry
- In the retail Industry
- In other industries

Exceleron meets the highest requirements placed on the accuracy and reliability of weighing results through the following features:

- Rugged construction and long service life
- Easy to clean and disinfect
- Easy to operate, thanks to the following features:
  - Large, backlit display segments
  - Large keys with positive click action
- Fast response times
- Automatic initialization when you switch on the Exceleron
- Optional: Control through an external computer

# Contents

| Description                                | Page |
|--|------|
| <b>Intended Use</b>                        | 2    |
| <b>Safety Precautions</b>                  | 3    |
| <b>Getting Started</b>                     | 5    |
| <b>General View of the Equipment</b>       | 6    |
| <b>Setting Up the Scale</b>                | 7    |
| <b>Operating Design</b>                    | 10   |
| <b>Descriptions of the Keys</b>            | 13   |
| <b>Configuration (Setup Menu)</b>          | 14   |
| <b>Application Programs</b>                | 16   |
| Counting                                   | 16   |
| Check Weighing                             | 17   |
| Toggleing between Weight Units             | 18   |
| <b>Calibration/Span Adjustment</b>         | 19   |
| <b>SBI Interface Protocol Descriptions</b> | 21   |
| <b>RS-232 Interface Diagram</b>            | 24   |
| <b>Print Formats</b>                       | 25   |
| <b>Error Codes</b>                         | 28   |
| <b>Care &amp; Maintenance</b>              | 29   |
| <b>Specifications</b>                      | 30   |
| <b>Accessories (Options)</b>               | 30   |
| <b>CE Marking</b>                          | 31   |

# Safety Precautions

## Explanation of Symbols:



Caution, risk of danger:  
Read the accompanying text carefully.



The instrument is double-insulated.



Protective conductor terminal



Earth ground terminal



## Safety tips, electrical protection class

This instrument was built and tested in accordance with the safety regulations for measuring and control instrumentation for protection class I (protective earth connection) according to IEC 1010/EN61010-1 or VDE 0411. The instrument was delivered in safe condition. To maintain this condition and to ensure safe operation, the operator must follow the instructions and warnings given in this documentation



## Protective earth

The connecting cable of the unit complies with the regulations in accordance with VDE 0411 or EN61010. The mains plug must contain a protective earth conductor, which must not be interrupted inside or outside this instrument (e.g. by using an extension cable without protective earth). Before commissioning, acceptance of the installation by a technically competent expert is required.



## Measurement category

This instrument is designed for measurement category I, with a maximum of 8.5V. To ensure safe operation do not use this instrument for measurements within the measurement categories II, III or IV.



## Opening the instrument

### CAUTION: DANGER TO LIFE!

- Working on the instrument when it is switched on can be dangerous to life. Disconnect the instrument from the supply voltage! When removing covers of parts by means of tools, live parts or terminals may be exposed. Capacitors in the unit may still be charged even after disconnecting the unit from all voltage sources.
- As the unit has no power switch, to completely remove AC power from the unit, disconnect the AC power cable from the mains socket.
- Do not expose the scale unnecessarily to aggressive chemical vapors or to extreme temperatures, moisture, shocks, or vibration.
- Avoid exposing the scale to static electricity; be sure to connect the equipotential bonding conductor to the junction box.

### Repair and maintenance

- Repairs are subject to checking and can be carried out only at Acculab. In case of defect or functional trouble, please contact your local Acculab organization for repair. When returning the instrument for repair, an exact and complete fault description must be supplied. Only a trained technician aware of the hazards involved may carry out maintenance work, during which the relevant precautions must be taken.

### Important note:

- Make sure that the construction of the instrument is not altered to the detriment of safety. In particular, leakage paths, air gaps (of live parts) and insulating layers must not be reduced. The manufacturer cannot be held responsible for personal injury or damage caused by an instrument repaired incorrectly by user or installer.

- Only authorized service technicians who have been trained by Acculab and who follow Acculab's standard operating procedures for maintenance and repair may open the scale. If you see any indication that the scale cannot be operated safely (for example, because of equipment damage), turn off the scale and lock it in a secure place so that it cannot be used for the time being.
- Suspension points are provided on platforms of 1,000 x 1,000 mm or larger. If you need to transport or lift the scale or load plate using a crane, do not step underneath the suspended scale or load plate. Be sure to observe the corresponding safety rules and regulations for prevention of accidents. Do not damage the scale or the load receptor during transportation.
- If you use suction lifting equipment to lift the load plate, always wear gloves, hard-toed safety boots and protective clothing. Warning: This procedure can cause personal injury! Only reliable personnel who are qualified to perform such work are allowed to use suction lifting equipment.
- Always make sure the scale is disconnected from AC power before performing any installation, cleaning, maintenance or repair work.
- Check the pin assignment if you use cables purchased from a different manufacturer. Before connecting such a cable to Acculab equipment, check the pin assignment on the corresponding wiring diagram or chart and disconnect any wires that are assigned differently from those specified by Acculab. The operator shall be solely responsible for any damage or injuries that may occur when using cables not supplied by Acculab.



**Note:**

- Do not use this equipment in hazardous areas.
- Make sure the voltage rating printed on the power supply is identical to your local line voltage.
- Use only commercially available batteries (rechargeable or dry-cell battery). If you use a rechargeable battery, use only 12V 2.3AH.
- The scale is energized at all times unless you disconnect the AC power and the battery.
- Exposure to excessive electromagnetic interference can cause the readout value to change. Once the disturbance has ceased, the instrument can be used again in accordance with its intended purpose.

# Getting Started

## Storage and Shipping Conditions

Do not expose the scale to shocks, vibrations, moisture or extreme temperatures.

## Unpacking the Scale

After unpacking the scale, check it immediately for any visible damage as a result of rough handling during shipment.

Note:

- The display and control unit is attached to the weighing platform via a cable.
- If you see any sign of damage, proceed as directed in the chapter entitled “Care and Maintenance,” under the section on “Safety Inspection.”
- Save the box and all parts of the packaging until you have successfully installed your scale. Only the original packaging provides the best protection for shipment. Before packing your scale, unplug all connected cables to prevent damage.

## Equipment Supplied

The equipment supplied includes the components listed below:

- Scale with attached display and control unit
- Load pan
- Installation and operating instructions

## Installation Instructions


The Acculab Exceleron scales are designed to provide reliable weighing results under normal ambient conditions. When choosing a location to set up your scale, observe the following so that you will be able to work with added speed and accuracy:

- Set up the scale on a stable, even surface
- Avoid placing the scale in close proximity to a heater or otherwise exposing the scale to heat or direct sunlight
- Protect the scale from drafts that come from open windows or doors
- Avoid exposing the scale to extreme vibrations during weighing
- Protect the scale from aggressive chemical vapors
- Do not expose the scale to extreme moisture over long periods

## Conditioning the Scale


Moisture in the air can condense on the surfaces of a cold scale whenever it is brought into a substantially warmer place. If you transfer the scale to a warmer area, make sure to condition it for about 2 hours at room temperature, leaving it unplugged from AC power. Afterwards, keep the scale continuously connected to AC power.

# General View of the Equipment




- 1 Manufacturer's ID tag
- 2 Housing
- 3 Power cable
- 4 Display and control unit retainer
- 5 Display and control unit column
- 6 Column support foot
- 7 Level indicator (option)
- 8 Leveling feet
- 9 Stainless steel weighing pan
- 10 Power plug
- 11 Cable gland cover (for optional RS-232 port outlet)
- 12 Load cell cable gland

## Setting Up the Scale




### Connecting Electronic Peripheral Devices

- Make absolutely sure to unplug the scale from AC power or switch off (activate battery mode) before you connect or disconnect a peripheral device (printer or PC) to or from the interface port.




### Warm-up Time

To deliver exact results, the scale must warm up for at least 30 minutes after initial connection to AC power. Only after this time will the scale have reached the required operating temperature.




### Leveling the Scale


- Remove the load plate
- Using the 4 foot screws, level the scale so that the air bubble is centered within the level indicator



- Check to ensure that all leveling feet rest securely on the work surface




- Under the metal frame structure there are four safety overload protection pins. The transportation protection nut is painted red (Note: not on all platform models)




Before using the scale, rotate the nut (upwards) until tight.

Place the load plate on the scale



### Assembly Procedure



1. Affix the column bracket with 4 screws
2. Install the column support leveling foot
3. Push the load-cell cable into the column
4. Insert the column into the bracket holder
5. Affix the column with 2 screws
6. Insert the display and control unit retainer into the column
7. Tighten the screw on the display and control unit bracket



### Battery-Powered Operation

To activate battery operation:

- Open the battery cover at the back of the Indicator.
- If you purchased the system with the dry-cell battery option, insert 1.5 V size D dry-cell batteries (not included) into the battery compartment.



- The battery symbol is displayed when the unit is operating on battery power.
- If the battery symbol flashes, the battery power is weak. Replace the batteries (if using dry-cell batteries).

# Operating Design

The scales in the Exceleron series consist of a weighing cell and a display and control unit. In addition to the choice of power supply or rechargeable maintenance free lead acid battery or dry battery, your scale also has an interface port for connecting peripheral devices, such as a printer, computer, etc.

The display and control unit is affixed to the weighing platform. Operation of the Exceleron scale is simple and uniform. The Exceleron models include the features like gross/net toggling, counting, checkweighing & unit toggling.

## Display

The display is divided into sections:

### Busy Symbol, Plus/Minus Sign

If the symbol displayed here is a triangle  $\triangle$ , this indicates that the scale is performing a function (busy symbol) a plus or minus sign (+ or -), this applies to the value displayed

### The Measured Value


Shows the measured value

### Basic Unit and Additional Information

- When the scale has stabilized, the weight unit is displayed here (g, kg,...).
- The Arrows below the weight indications shows the weighing mode (gross/net) and the application mode (counting, checkweighing, or unit toggling) enabled, if any.
- The  $\triangle$  symbol indicates the unit is not in weighing mode (e.g.: calibration mode, configuration mode, error mode)

### Load Cell Connection

- Attach the wires to the screw terminals in the indicator (see "Pin Assignment")




| No | Signal       | Meaning                    |
|----|--------------|----------------------------|
| 1  | + Excitation | Supply voltage positive    |
| 2  | + Sense      | Sense positive             |
| 3  | + Output     | Measuring voltage positive |
| 4  | - Output     | Measuring voltage negative |
| 5  | - Sense      | Sense negative             |
| 6  | - Excitation | Supply voltage negative    |

### Load cell color code

| Terminal assignment | 1   | 2    | 3     | 4     | 5               | 6     |
|---------------------|-----|------|-------|-------|-----------------|-------|
| For load cell type: |     |      |       |       |                 |       |
| 4-conductor         | red |      | green | white |                 | black |
| 6-conductor         | red | blue | green | white | brown or yellow | black |

\* For 4-conductor load cell - Pin 1, 2 and Pin 5, 6 connected with a jumper wire.



### Operating Limits

Never exceed the maximum capacity of the scale.

The maximum loading capacities of the scale in this series are listed in the table below, and depend on the position of the load on platform:

| Model  | Width (mm) | Length (mm) | Center* | Side | Corner |
|--------|------------|-------------|---------|------|--------|
| ECL6   | 240        | 320         | 50      | 35   | 20     |
| ECL15  | 300        | 400         | 130     | 85   | 45     |
| ECL30  | 400        | 500         | 500     | 400  | 200    |
| ECL60  | 500        | 650         | 600     | 400  | 200    |
| ECL150 | 700        | 700         | 600     | 400  | 200    |
| ECL300 | 600        | 800         | 600     | 400  | 200    |

# Power Management Option

## Scale connected to AC power:

### On/Off Switch:

On: Scale is operational & display shows function or mode that is in use

Off: Depends on menu setting ("4. Standby option."), scale is completely off (no display and no internal circuitry) or in standby (no display and internal circuitry working).

### Back Light:

Depends on menu setting ("2. Backlight"). Backlight is on/off.

### Auto Power Off:

Not active.

## Scale running on battery power:

### On/Off Switch:

On: Scale is operational and the display shows the function or mode that is in use

Off: Completely off (no display and no internal circuitry)


### Back Light:

Depends on menu setting ("2. Backlight"). Backlight is on/off. Backlight goes off after 15 seconds if no operation is done (no key pressed/no weighing). Backlight comes back on whenever a key (except on/off) is pressed or when a load is placed on the scale.

### Auto Power Off:

Depends on menu setting ("3. Auto power off"); system power shuts down. Time limit options for auto power in setup menu are 5, 10 or 15 minutes, or can be disabled.

## Descriptions of the Keys



### 1) On/Off

“on/off” function will depend on different power supply condition. Needs setup menu for backlight control and for auto power off.

#### In Main Mode

#### ● Off-Mode:

If standby active: Scale is in standby mode but there is no display visible other than mode symbol (no backlight, no display, no symbols)

If standby not active: scale is completely off

#### ● On-Mode:

Scale is in operation and the display shows the function, that is in use.

In this mode, auto power off function is invalid.

#### In Battery Mode

#### ● Off-Mode:

Scale is completely off.

#### ● On-Mode:

Scale is in operation and the display shows the function, which is in use. Backlight works based on setup menu

In this mode, auto power off function is valid. After 5, 10 or 15 minutes, the system shuts off when not in use in accordance with the setup menu setting.

### 2) Zero/Arrow-Left (ZERO/LEFT)

Weighing mode: Set scale to zero

Parameter mode: Shift position of digit to the left

### 3) Tare/Arrow-Right (TARE/RIGHT)

Weighing mode: Tare the scale

Parameter mode: Shift position of digit to the right

### 4) Gross-Net/Arrow-Down (G/N/DOWN)

Weighing mode: Toggle weight unit gross/net

Counting mode: Toggle weight unit gross, net and pcs

Function mode: To scroll down menu selection

Parameter mode: Reduce digit value by 1

### 5) Function/Arrow-Up (Fn/UP)

Weighing mode: Switch the scale from normal weighing mode to application setup mode

Function mode: Scroll up in menu selection

Parameter mode: Increment digit



### 6) Print/Enter (PRINT/ENTER)

Weighing mode: Print key

Function mode: Scroll level up in menu mode/confirm menu selected.


# Configuration (Setup Menu)

To configure the user interface of the scale to individual requirements

| Step                                     | Key (or instruction) | Display   |
|--|----------------------|---|
| 1. Switch off the scale                  | (ON/OFF)             |  |
| 2. Switch on the scale                   | (ON/OFF)             |  |
| 3. While all the segments are displayed: | (ZERO/LEFT) > 2 sec  |   |












## Navigation in the Setup Menu

| Key           | Function   |
|---------------|--|
| (PRINT/ENTER) | Menu item: confirm setting                         |
| (Fn/UP)       | Menu item: Scroll up<br>Digit input: Increment     |
| (G/N/DOWN)    | Menu item: Scroll down<br>Digit input: Reduce by 1 |
| (ZERO/LEFT)   | Digit input: Selection shift left                  |
| (TARE/RIGHT)  | Digit input: Selection shift right                 |














# Application Programs










## Counting

| Step  | Key (or instruction)             | Display   |
|---|----------------------------------|---|
| a. Select application program   | (Fn/UP) > 2 sec                  |    |
| b. Select "Counting"  | (Fn/UP) or (G/N/DOWN) repeatedly |    |
| c. Press PRINT/ENTER.<br>Display shows reference piece selection menu.<br>Counting is blinking.                               | (PRINT/ENTER)                    |    |
| d. Automatically the display will show the reference pieces.<br>Place container and press Tare if required (display "tared"). | (TARE/RIGHT)                     |    |
| e. Select reference sample quantity: 5, 10, 20, 50 or 100, and put the reference on the scale. (quantity flashes)             | (Fn/UP) or (G/N/DOWN) repeatedly |    |
| f. Press PRINT/ENTER. Now "0" flashes.<br>Automatic optimization is active.   | (PRINT/ENTER)                    |    |
| g. Place more reference samples on scale<br>(The number is x+2~2x times of the reference pieces (x) selected in step e.)      |                                  |   |
| h. Place uncounted parts/samples on the scale   |                                  |  |
| i. Toggle between reference piece weight, (G/N/DOWN) total weight, and total pieces.  |                                  |  |
| j. Unload the scale   |                                  |  |
| k. Counting application: Clear  | (ZERO/LEFT) > 2 sec              |  |

## Check Weighing







| Step   | Key (or instruction)                                     | Display  |
|--|--|--|
| a. Select application program  | (Fn/UP) > 2 sec  |    |
| b. Select "Checkweighing"  | (Fn/UP) or (G/N/DOWN) Repeatedly                         |    |
| c. Press PRINT/ENTER to confirm.   | (PRINT/ENTER)  |    |
| d. Set lower limit; "LO" flashes.  | (Fn/UP) or (G/N/DOWN) and/or (ZERO/LEFT) or (TARE/RIGHT) |    |
| e. Press PRINT/ENTER to confirm and save.  | (PRINT/ENTER)  |    |
| f. Set upper limit; "HI" flashes, and then press PRINT/ENTER.                      | (Fn/UP) or (G/N/DOWN) and/or (ZERO/LEFT) or (TARE/RIGHT) |    |
| g. Press PRINT/ENTER to confirm and save.  | (PRINT/ENTER)  |    |
| h. Place the sample on the scale.<br>Display shows the difference and HI/LO symbol |  | <br> |
| i. Unload the scale  |  |    |
| j. Checkweighing application: Clear  | (ZERO/LEFT) > 2 sec                                      |    |

## Toggling between Weight Units













| Step  | Key (or instruction)             | Display   |
|---|----------------------------------|---|
| a. Select application program   | (Fn/UP) > 2 sec                  |    |
| b. Select "Toggling Weight Units"                                       | (Fn/UP) or (G/N/DOWN) Repeatedly |    |
| c. Select weight unit 1   | (Fn/UP) or (G/N/DOWN)            |    |
| d. Confirm weight unit 1  | (PRINT/ENTER)                    |    |
| e. Select weight unit 2   | (Fn/UP) or (G/N/DOWN)            |    |
| f. Confirm weight unit 2  | (PRINT/ENTER)                    |    |
| g. Place sample on the scale  |                                  |    |
| h. Toggle weight unit   | (Fn/UP)                          |   |
| i. Unit toggling Application:<br>Clear (unit changes to basic unit set) | (ZERO/LEFT) > 2 sec              |  |

# Calibration/Span Adjustment

## Calibrate the Scale

| Step  | Key (or instruction)             | Display  |
|---|----------------------------------|--|
| a. Switch on the scale  | (ON/OFF)                         |  |
| b. Zero the scale   | (ZERO/LEFT)                      |  |
| c. Select calibration/linearization mode  | (TARE/RIGHT) > 2 Sec             |  |
| d. Select calibration   | (Fn/UP) or (G/N/DOWN) Repeatedly |  |
| e. Confirm/start calibration.<br>After the zero point is stored, the required calibration weight is displayed   | (PRINT/ENTER)                    |  |
| f. Place the required weight on the scale   |                                  |  |
| g. If the weight is applied within the defined time limit and tolerance, the "OK" symbol is displayed.<br>Press "(PRINT/ENTER)" to confirm and save calibration.<br>(To exit calibration press (ZERO/LEFT) > 2 sec) | (PRINT/ENTER)                    |  |

## Linearize the Scale

| Step   | Key (or instruction)             | Display   |
|--|----------------------------------|---|
| a. Switch on the scale   | (ON/OFF)                         |    |
| b. Zero the scale  | (ZERO/LEFT)                      |    |
| c. Select calibration/linearization mode   | (TARE/RIGHT) > 2 sec             |    |
| d. Select linearization  | (Fn/UP) or (G/N/DOWN) repeatedly |    |
| e. Confirm/start linearization<br>After the zero point is stored, the required linearization weight is displayed.  | (PRINT/ENTER)                    |    |
| f. Place the required weight on the scale  |                                  |    |
| g. If the weight is applied within the defined time limit and tolerance, the "OK" symbol is displayed. Press "(PRINT/ENTER)" to confirm and save calibration. (To exit linearization, press (ZERO/LEFT) > 2 sec) | (PRINT/ENTER)                    |    |
| h. The next linearization weight will be shown on the display after confirmation of the previous linearization weight.   |                                  |   |
| i. Place the required weight on the scale.   |                                  |  |
| j. If the weight is applied within the defined time limit and tolerance, the "OK" symbol is displayed. Press "(PRINT/ENTER)" to confirm and save calibration. (To exit linearization, press (ZERO/LEFT) > 2 sec) | (PRINT/ENTER)                    |  |
| k. Remove the linearization weight   |                                  |  |
| l. Linearization complete  |                                  |  |

# SBI Interface Protocol Description

Output Format with 22 Characters

The following data block format is output:

I I I I I I V W W W W W W W W U U U CR LF

---

I : ID  
 V : +/- sign  
 W : Weight value  
 U : Unit

## ID Codes

S t a t Indicates a special weighing platform status, e.g., initialization, self-test, adjustment/calibration  
 N Indicates net or gross value  
 N 1 Indicates net value with 1<sup>st</sup> tare memory assigned (not main tare)  
 N 2 Indicates net value with 2<sup>nd</sup> tare memory assigned (not main tare)  
 S / N Indicates equipment serial number  
 M o d e l Indicates equipment Model

## Plus/Minus Sign

+ Plus sign  
 - Minus sign

Space (i.e., no plus or minus sign; if weight value is 0 or if output does not include a weighed value)

## Unit

No stable parameter.; no weighed value  
 g Grams  
 k g Kilograms  
 l b Pounds  
 o z Ounces  
 t Tons

## Special Codes

The data block may contain special information.

Special status-dependent codes:

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22  
 S1 S2 CR LF

---

The following status codes are output for "S1" and "S2":

: Taring  
 C : Internal calibration  
 -- : All numerals shown in stable readout  
 H : Overload  
 L : Underload

### Special Error-dependent Codes:

|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 |
|   |   |   |   |   |   |   |   |   | E  | R  | R  |    | n  | n1 | n2 |    |    |    |    | CR | LF |

n – n3 contains an error code of up to 3 digits.

## Data Input Formats

You can enter certain commands to control weighing platform functions through the SBI interface.

As with data output, data is input as 7-bit ASCII characters; hardware and protocol configuration are identical to those for data output.

### Formats:

ESC K CR LF

ESC K K1 - CR LF

- ESC : Escape
- K : Command character
- K1 : 2<sup>nd</sup> command character (number)
- : Underline
- CR : Carriage return
- LF : Line feed

The CR and LF characters do not have to be transmitted in the data string.

### **Control Commands**

ESC P CR LF Print, auto print: initiate / stop

ESC T CR LF Zero/Tare – combination

ESC V CR LF Zero the weighing platform

ESC U CR LF Tare the weighing platform

ESC S CR LF Reset

ESC O CR LF Lock keyboard

ESC R CR LF Unlock keyboard

ESC x 1 \_ CR LF Output model name

ESC x 2 \_ CR LF Output serial number

### **Adaptation to Ambient Conditions**

ESC K CR LF Very stable

ESC L CR LF Stable

ESC M CR LF Unstable

ESC N CR LF Very unstable

# RS-232 Interface Diagram





Diagram for interfacing a computer or different peripheral device to the scale using RS-232 cable length up to 15 m.

# Print Formats

## Printing Mode Options

| Printing out Options |                                  |   |   |
|----------------------|----------------------------------|---|---|
| Mode of operation    | Short print                      | Block print (long print)  | Continuous mode   |
| Normal weighing mode | Net weight                       | Gross weight (if tare is active)<br>Tare weight (if tare is active)<br>Net weight   | Gross weight (if tare is not active)<br>or<br>Net weight (if tare is active)  |
| Counting mode        | Net weight<br>Pcs<br>Ref. weight | Gross weight (if tare is active)<br>Tare weight (if tare is active)<br>Net weight<br>Pcs<br>Ref. weight                                   | Pcs (default)<br><br>By pressing G/N key, it can switch to:<br>Gross weight (if tare is not active)<br>or<br>Net weight (if tare is active) |
| Checkweighing mode   | Net weight<br>Chk OK/LO/HI       | Gross weight (if tare is active)<br>Tare weight (if tare is active)<br>Net weight<br>Chk OK/LO/HI<br>LL (lower limit)<br>HH (upper limit) | Press key to toggle between:<br>Gross weight (with unit 1)<br>and<br>Gross weight (with unit 2)   |

The print output can be configured for three modes: short mode (option 1.3.1), long/block mode (option 1.3.2) and continuous mode (option 1.3.3). The SBI interface, explained in the section above, is available in all modes. Sample print outputs are given below for all three printing options in different weighing modes.

Note: To configure serial communication settings and print output options, please refer to "Configuration (Setup menu)". Refer to "Application Programs" to configure the display and control unit for different weighing modes.

### a. Print output: Expansion of Abbreviations

|        |   |
|--------|---|
| N      | Net weight  |
| G      | Gross weight  |
| T      | Tare weight (appears in block printing mode, if tare is not zero) |
| Chk.   | Checkweighing status (If checkweighing application is selected)   |
| OK     | Ok (checkweighing mode, if the placed weight is in the range set) |
| HI     | High  |
| LO     | Low   |
| LL     | Lower limit (checkweighing)                                       |
| HL     | Higher limit (checkweighing)                                      |
| W.Ref. | Reference weight (counting application)                           |
| Pcs    | Number of units on the pan  |
| g      | Weight in Grams   |
| kg     | Weight in kilograms   |
| +      | Appears if the value is greater than or equal to zero             |
| -      | Appears if the value is less than zero                            |

## b. Sample print outputs in different applications

### 1. Short printing mode:

#### 1.1 Normal weighing

G + 200 g

#### 1.2 Counting

N + 400 g  
Pcs 10 pcs  
W. Ref. 40 g

#### 1.3 Checkweighing

Ex 1: If the weight on the pan is <10% of lower limit set.

N + 0 g  
Chk.

Ex 2: If the weight on the pan < lower limit set.

N + 100 g  
Chk. LO

Ex 3: If the weight on the pan is between the set limits.

N + 200 g  
Chk. OK

Ex 4: If the weight on the pan > upper limit set.

N + 410 g  
Chk. HI

#### 1.4 Unit toggling

Ex 1: Before toggle key is pressed

G + 300 g

Ex 2: After unit is toggled to kilograms.

G + 0.300 kg

### 2. Block printing mode:

#### 2.1 Normal weighing

Ex 1: If tare is zero

G + 200 g

Ex 2: If tare is not zero

G + 100 g  
T + 50 g  
N + 50 g

#### 2.2 Counting mode

Ex 1: If tare is zero.

G + 400 g  
Pcs 10 pcs  
W. Ref. 40 g

Ex 2: If tare value is set.

G + 440 g  
T + 400 g  
N + 80 g  
Pcs 2 pcs  
W. Ref. 40 g

#### 2.3 Check weighing mode

Ex 1: If the weight on the pan is <10% of lower limit set, with zero tare.

G + 0 g  
Chk.  
LL 200 g  
HL 400 g

Ex 2: If the weight on the pan < lower limit set, with zero tare.

G + 100 g  
Chk. LO  
LL 200 g  
HL 400 g

Ex 3: If the weight on the pan is between the set limits, with zero tare.

G + 200 g  
Chk. OK  
LL 200 g  
HL 400 g

Ex 4: If the weight on the pan > upper limit set.

|      |   |     |   |
|------|---|-----|---|
| G    | + | 410 | g |
| Chk. |   | HI  |   |
| LL   |   | 200 | g |
| HL   |   | 400 | g |

Ex 5: If the weight on the pan is <10% of lower limit set, with a set tare value.

|      |   |     |   |
|------|---|-----|---|
| G    | + | 400 | g |
| T    | + | 400 | g |
| N    | + | 0   | g |
| Chk. |   |     |   |
| LL   |   | 200 | g |
| HL   |   | 400 | g |

Ex 6: If the weight on the pan < lower limit set, with a set tare value.

|      |   |     |   |
|------|---|-----|---|
| G    | + | 800 | g |
| T    | + | 400 | g |
| N    | + | 400 | g |
| Chk. |   | OK  |   |
| LL   |   | 200 | g |
| HL   |   | 400 | g |

Ex 7: If the weight on the pan > upper limit set, with tare value set.

|      |   |     |   |
|------|---|-----|---|
| G    | + | 810 | g |
| T    | + | 400 | g |
| N    | + | 410 | g |
| Chk. |   | HI  |   |
| LL   |   | 200 | g |
| HL   |   | 400 | g |

#### 2.4 Unit toggling

Ex 1: Before toggle key is pressed.

|   |   |     |   |
|---|---|-----|---|
| G | + | 300 | g |
| T | + | 200 | g |
| N | + | 100 | g |

Ex 2: After unit is toggled to kilograms.

|   |   |       |    |
|---|---|-------|----|
| G | + | 0.300 | kg |
| T | + | 0.200 | kg |
| N | + | 0.100 | kg |

### 3. Continuous printing mode

#### 3.1 Normal weighing

Ex 1: If tare is not active

|   |   |     |   |
|---|---|-----|---|
| G | + | 200 | g |
|---|---|-----|---|

Ex 2: If tare value is present.

|   |   |     |   |
|---|---|-----|---|
| N | + | 200 | g |
|---|---|-----|---|

#### 3.2 Counting mode

default:

|     |  |   |     |
|-----|--|---|-----|
| Pcs |  | 2 | Pcs |
|-----|--|---|-----|

Ex 1: If tare is not active (G/N key)

|   |   |     |   |
|---|---|-----|---|
| G | + | 200 | g |
|---|---|-----|---|

Ex 2: If tare Value is present. (G/N key)

|   |   |     |   |
|---|---|-----|---|
| N | + | 200 | g |
|---|---|-----|---|

#### 3.3 Checkweighing

Ex 1: If tare is not active

|   |   |     |   |
|---|---|-----|---|
| G | + | 200 | g |
|---|---|-----|---|

Ex 2: If tare value is present.

|   |   |     |   |
|---|---|-----|---|
| N | + | 200 | g |
|---|---|-----|---|

#### 3.4 Unit toggling

Output 1: Before toggle key is pressed

|   |   |     |   |
|---|---|-----|---|
| G | + | 300 | g |
|---|---|-----|---|

Output 2: After the unit is toggled to kilograms.

|   |   |       |    |
|---|---|-------|----|
| G | + | 0.300 | kg |
|---|---|-------|----|

# Error Codes

Error codes are shown on the main display. “Err” codes are shown continuously; “Inf.” messages are shown for 2 seconds, after which the program returns automatically to the weighing mode.

| <b>Problem</b>   | <b>Cause</b>  | <b>Solution</b>   |
|--|---|---|
| Nothing appears or some symbols exist desultorily on the display | <ul style="list-style-type: none"> <li>– No power available</li> <li>– The AC adapter is not plugged in</li> <li>– Battery is drained</li> <li>– LCD cable is loose</li> </ul>        | <ul style="list-style-type: none"> <li>– Check the power supply</li> <li>– Plug in the AC adapter</li> <li>– Replace battery; charge battery using external charger</li> <li>– Plug in the cable again or contact customer service</li> </ul> |
| <i>oL</i>  | <ul style="list-style-type: none"> <li>– The load exceeds the scale capacity</li> </ul>   | <ul style="list-style-type: none"> <li>– Unload the scale</li> </ul>  |
| <i>uL</i>  | <ul style="list-style-type: none"> <li>– Weighing pan is not in place</li> <li>– Something is touching the weighing pan</li> </ul>  | <ul style="list-style-type: none"> <li>– Place the weighing pan on the pan</li> <li>– Move the object that is touching the weighing pan</li> </ul>  |
| <i>dSPErr</i>  | <ul style="list-style-type: none"> <li>– Display overflow:<br/>Value cannot be shown on the display</li> </ul>  | <ul style="list-style-type: none"> <li>– Reduce the load on the scale</li> </ul>  |
| <i>CALErr</i>  | <ul style="list-style-type: none"> <li>– Calibration parameter not met; e.g.:<br/>– scale not zeroed<br/>– scale is loaded<br/>– scale setting not allowed to the customer</li> </ul> | <ul style="list-style-type: none"> <li>– Calibrate only when zero is displayed</li> <li>– Press (zero) to tare the scale</li> <li>– Unload the scale</li> </ul>   |
| <i>APPErr</i>  | <ul style="list-style-type: none"> <li>– Weight is too high or there is no sample on the scale with application in use</li> </ul>   | <ul style="list-style-type: none"> <li>– Increase the weight on the scale</li> </ul>  |
| <i>PrtErr</i>  | <ul style="list-style-type: none"> <li>– Data interface for printing is blocked</li> </ul>  | <ul style="list-style-type: none"> <li>– Contact the customer service center</li> </ul>   |
| <i>SYSErr</i>  | <ul style="list-style-type: none"> <li>– APP board cannot retrieve data from AD board</li> </ul>  | <ul style="list-style-type: none"> <li>– Contact customer service</li> </ul>  |
| <i>EPErr</i>   | <ul style="list-style-type: none"> <li>– EEPROM defective</li> </ul>  | <ul style="list-style-type: none"> <li>– Contact customer service</li> </ul>  |
| <i>FnErr</i>   | <ul style="list-style-type: none"> <li>– Function not allowed in scales verified for use in legal metrology</li> </ul>  | <ul style="list-style-type: none"> <li>– Contact customer service</li> </ul>  |
| <i>Sb iErr</i>   | <ul style="list-style-type: none"> <li>– SBI command error</li> </ul>   | <ul style="list-style-type: none"> <li>– Contact customer service</li> </ul>  |
| <i>Err 0B</i>  | <ul style="list-style-type: none"> <li>– Zero is not possible if weight value is more than 10% of FSD</li> </ul>  | <ul style="list-style-type: none"> <li>– Zero the scale after removing some of the load</li> </ul>  |
| <i>Err 09</i>  | <ul style="list-style-type: none"> <li>– Tare is not possible when the gross weight is a minus value</li> </ul>   | <ul style="list-style-type: none"> <li>– Zero the scale</li> </ul>  |
| <i>FEErr</i>   | <ul style="list-style-type: none"> <li>– Fatal error; cause unknown</li> </ul>  | <ul style="list-style-type: none"> <li>– Contact customer service</li> </ul>  |
| <i>Err 54</i><br><i>Err 55</i>                                   | <ul style="list-style-type: none"> <li>– No platform is connected</li> </ul>  | <ul style="list-style-type: none"> <li>– Connect a platform or sensor</li> </ul>  |
| Max. Weighing capacity is less than indicated under “calibrate”  | <ul style="list-style-type: none"> <li>– The scale was switched on without the weighing pan in place</li> </ul>   | <ul style="list-style-type: none"> <li>– Place the weighing pan on the scale and press “On/Off”</li> </ul>  |
| The weight readout is obviously wrong                            | <ul style="list-style-type: none"> <li>– The scale was not calibrated/adjusted before weighing</li> <li>– Scale not zeroed</li> </ul>   | <ul style="list-style-type: none"> <li>– Calibrate/adjusted the scale</li> <li>– Zero the scale</li> </ul>  |

# Care and Maintenance

## Cleaning

- Unplug the scale from the AC power before cleaning.
- To clean the weighing platform: use a piece of cloth, wet with a commercially available cleaning agent (IPA – Isopropyl Alcohol) to wipe it down. Follow the manufacturer's instructions for the cleaning agent.



**Never use concentrated acids, bases, solvents or pure alcohol to clean the weighing platform.**



**Do not use high-pressure cleaning equipment to clean the weighing platform.**

- If the scale is installed in a pit, make sure that no debris builds up in the crevices between the pit and the platform, to prevent weighing errors.
- Regularly remove debris from the bottom of the pit.

## Cleaning the Inside of the Platform

- To clean the inside of the weighing platform, remove the load plate (applicable for single load cell platforms).



**Please follow the safety instructions.**

- **Use compressed air to blow debris out of the inside of the scale. Make sure that no debris builds up in the gap between the load receptor and the fastening plate, to avoid compromising the overload protection.**

## Corrosive Environment

- Remove all traces of corrosive substances from the weighing platform on a regular basis.

## Safety Inspection

If there is any indication that safe operation of the scale with the AC is no longer warranted:

- Turn off the power and disconnect the equipment from AC power immediately
- Lock the equipment in a secure place to ensure that it cannot be used for the time being

Safe operation of the scale with the AC is no longer ensured when:

- There is visible damage to the AC adapter
- The AC adapter no longer functions properly
- The AC adapter has been stored for a relatively long period under unfavorable conditions

In this case, notify your nearest service center or the International Technical Support. Maintenance and repair work may only be performed by service technicians who

- Have access to the required maintenance manuals
- Have attended the relevant service training courses

## Instructions for Recycling the Packaging

To ensure safe shipment, your scale has been packaged using environmentally friendly materials. After successful installation of the scale, you should return this packaging for recycling. For information on recycling options, including recycling of old weighing equipment, contact your municipal waste disposal center or local recycling depot.

# Specifications

|                      |   |
|----------------------|---|
| No of keys           | 6   |
| Display              | LCD, 6 digits, character height: 25 mm, 7 segment with backlight (amber)  |
| Functions            | 1. Zero, 2. Tare, 3. Counting, 4. Checkweighing, 5. Net/gross weight, 6. Toggle between weight units, 7. Auto power off (optional battery mode) |
| Maximum readability  | 15000d  |
| Temperature range    | -10 to +40°C RH85% no condensation  |
| Line power supply    | Built-in 100-240V AC (+/- 10%), 50Hz, 15.5 VA (with battery charger circuit)<br>4 VA (without battery charger circuit)                          |
| DC power operation   | Optional using 6 "D" size 1.5V dry battery  |
| Load plate           | Platform code: DC, ED, FE, GF, GG, IG stainless steel; LL, NL, NN, RN, RR, WR painted steel   |
| Housing material     | ABS   |
| Column               | Length 350 mm, 500 mm & 750 mm  |
| Measurement category | Category 1, maximum 8.5V  |
| Pollution degree     | Degree 2  |
| Compliance           | CE  |

## Specifications of the Individual Models:

| Model                         | ECL6EDP     | FCC15EDP | ECL30EDP | ECL60EDP | ECL150EDP | ECL150EDP |
|-------------------------------|-------------|----------|----------|----------|-----------|-----------|
| Weighing capacity (kg)        | 6           | 15       | 30       | 60       | 150       | 300       |
| Verification (g)              | 0.5         | 1        | 2        | 5        | 10        | 100       |
| Readability ( $\times\pm g$ ) | 1           | 2        | 4        | 10       | 20        | 100       |
| Linearity ( $\times\pm g$ )   | 1           | 2        | 4        | 10       | 20        | 100       |
| Operating temperature         | -10...+40°C |          |          |          |           |           |

## Accessories (Options)

- RS-232 interface (cable 2 m with DB9 pins for PC connection)
- RS-232 interface (cable 2 m with DB25 pins for YDPO3 printer)
- Printer YDPO3-OCE

# CE Marking

The scale complies with the following EC Directives and European Standards:

## **Directive 2004/108/EC: “Electromagnetic compatibility (EMC)”**

- EN 61326-1** Electrical equipment for measurement, control and laboratory use  
EMC Requirements
- Part 1:** General requirements  
Defined immunity to interference:  
Industrial areas, continuous,  
unmonitored operation  
Limitation of emissions:  
Residential areas, Class B

### **Important Note:**

The operator shall be responsible for any modifications to Acculab equipment or connections of cables not supplied by Acculab and must check and, if necessary, correct these modifications.

On request, Acculab will provide information on the minimum operating specifications (in accordance with the Standards listed above for defined immunity to interference).

## **Directive 2006/95/EC: “Electrical equipment designed for use within certain voltage limits”**

Applicable European Standards:

- EN 61010** Safety requirements for electrical measurement, control, and laboratory equipment  
Part 1: General requirements

If you use electrical equipment in installations and under ambient conditions subject to stricter safety standards than those described in the manual, you must comply with the provisions as specified in the applicable regulations for installation in your country.

Address label/Dealer's stamp

Copyright by Acculab.

All rights reserved. No part of this publication may be reprinted or translated in any form or by any means without the prior written permission of Acculab.

The status of the information, specifications and illustrations in this manual is indicated by the date given below.

Acculab reserves the right to make changes to the technology, features, specifications and design of the equipment without notice.

Status:

July 2008, Acculab