


# Jewelry Balances

## JP/JS Models



**METTLER TOLEDO**



## Table of contents

<b>1</b>	<b>Introduction</b>		<b>7</b>
	1.1	Conventions and Symbols Used in These Operating Instructions	7
<b>2</b>	<b>Safety Precautions</b>		<b>8</b>
<b>3</b>	<b>Overview</b>		<b>9</b>
	3.1	Components	9
	3.2	Operation Keys	10
	3.3	Display Panel	11
<b>4</b>	<b>Setting up the Balance</b>		<b>13</b>
	4.1	Unpacking and Delivery Inspection	13
	4.2	Installing the Components	13
	4.3	Selecting the Location and Leveling the Balance	14
	4.3.1	Selecting the Location	15
	4.3.2	Leveling the Balance	15
	4.4	Power Supply	15
	4.4.1	AC Operation	16
	4.4.2	Battery Operation	16
	4.5	Transporting the Balance	17
	4.6	Weighing Below the Balance	17
	4.7	Adjustment (Calibration)	18
	4.7.1	Fully Automatic Adjustment FACT	18
	4.7.2	Adjustment with Internal Weight	18
	4.7.3	Adjustment with External Weight	19
<b>5</b>	<b>Weighing Made Simple</b>		<b>21</b>
	5.1	Switching the Balance On and Off	21
	5.2	Performing a Simple Weighing	22
	5.3	Zero Setting / Taring	22
	5.4	Switching Weight Units	22
	5.5	Recall / Recall Weight Value	23
	5.6	Weighing with the Weighing-in Aid	23
	5.7	Print / Transmit Data	23
<b>6</b>	<b>The Menu</b>		<b>24</b>
	6.1	What is in the Menu ?	24
	6.2	Menu Operation	25
	6.3	Description of Menu Topics	26
	6.3.1	Main Menu	26
	6.3.2	Basic Menu	26
	6.3.3	Advanced Menu	28
	6.3.4	Interface Menu	31
<b>7</b>	<b>Applications</b>		<b>36</b>
	7.1	Application "Piece Counting"	36
	7.2	Application "Percent Weighing"	38
	7.3	Application "Check Weighing"	40

7.4	Application "Statistics"	43
7.5	Application "Totaling"	45
7.6	Application "Multiplication Factor Weighing"	47
7.7	Application "Division Factor Weighing"	49
7.8	Application "Density"	51
7.8.1	Density Determination of Solids	51
7.8.2	Density Determination of Liquids	53
7.8.3	Formulae Used to Calculate Density	54
7.9	Application "Routine Test"	57
7.10	Application "Diagnostics"	60
7.10.1	Repeatability Test	60
7.10.2	Display Test	61
7.10.3	Key Test	62
7.10.4	Motor Test	63
7.10.5	Balance History	63
7.10.6	Calibration History	64
7.10.7	Balance Information	65
7.10.8	Service Provider Information	66
<b>8</b>	<b>Communication with Peripheral Devices</b>	<b>67</b>
8.1	Function PC-Direct	67
<b>9</b>	<b>Firmware (Software) Updates</b>	<b>69</b>
9.1	Operating Principle	69
9.2	Update Procedure	69
<b>10</b>	<b>Error and Status Messages</b>	<b>70</b>
10.1	Error Messages	70
10.2	Status Messages	70
<b>11</b>	<b>Cleaning and Service</b>	<b>72</b>
<b>12</b>	<b>Interface Specification</b>	<b>73</b>
12.1	RS232C Interface	73
12.2	MT-SICS Interface Commands and Functions	73
<b>13</b>	<b>Technical Data</b>	<b>76</b>
13.1	General Data	76
13.2	Model-Specific Data	76
13.2.1	Carat Balances with Readability of 0.001 ct	76
13.2.2	Gold Balances with Readability of 0.001 g	77
13.2.3	Gold Balances with Readability of 0.01 g	78
13.2.4	Gold Balances with Readability of 0.1 g	80
13.3	Dimensions	82
13.3.1	Carat Balances with Readability of 0.001 ct	82
13.3.2	Gold Balances with Readability of 0.001 g	83
13.3.3	Gold Balances with Readability of 0.01 g	84
13.3.4	Gold Balances with Readability of 0.1 g	85
<b>14</b>	<b>Accessories and Spare Parts</b>	<b>86</b>
14.1	Accessories	86

		14.2	Spare Parts	89
<b>15</b>	<b>Appendix</b>			<b>91</b>
		15.1	Conversion Table for Weight Units	91
		15.2	Recommended Printer Settings	91
<b>16</b>	<b>Index</b>			<b>92</b>



# 1 Introduction

Thank you for choosing a METTLER TOLEDO balance.


The precision balances of the Jewelry line combine a large number of weighing possibilities with easy operation.

These operating instructions

- apply to all balance models JP/JS in the Jewelry line.
- are based on the initially installed firmware (software) version V1.50.

However, the different models have different characteristics regarding equipment and performance. Special notes in the text indicate where this makes a difference to operation.

## 1.1 Conventions and Symbols Used in These Operating Instructions

Key designations are indicated by double angular brackets (e.g. «»).



This symbol indicates press key briefly (less than 1.5 s).



This symbol indicates press and hold key down (longer than 1.5 s).




This symbol indicates a flashing display.



This symbol indicates an automatic sequence.



These symbols indicate safety notes and hazard warnings which, if ignored, can cause personal danger to the user, damage to the balance or other equipment, or malfunctioning of the balance.



This symbol indicates additional information and notes. These make working with your balance easier, as well as ensuring that you use it correctly and economically.

## 2 Safety Precautions

Always operate and use your balance only in accordance with the instructions contained in this manual. The instructions for setting up your new balance must be strictly observed.

**If the balance is not used according to these Operating Instructions, protection of the balance may be impaired and METTLER TOLEDO assumes no liability.**



It is not permitted to use the balance in explosive atmosphere of gases, steam, fog, dust and flammable dust (hazardous environments).



For use only in dry interior rooms.

Do not use sharply pointed objects to operate the keyboard of your balance! Although your balance is very ruggedly constructed, it is nevertheless a precision instrument. Treat it with corresponding care.

Do not open the balance: It does not contain any parts which can be maintained, repaired, or replaced by the user. If you ever have problems with your balance, contact your METTLER TOLEDO dealer.

Use only balance accessories and peripheral devices from METTLER TOLEDO; they are optimally adapted to your balance.



Use only the original universal AC adapter delivered with your balance.



### Disposal

In conformance with the European Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE) this device may not be disposed of in domestic waste. This also applies to countries outside the EU, per their specific requirements.


Please dispose of this product in accordance with local regulations at the collecting point specified for electrical and electronic equipment. If you have any questions, please contact the responsible authority or the distributor from which you purchased this device. Should this device be passed on to other parties (for private or professional use), the content of this regulation must also be related.

Thank you for your contribution to environmental protection.




## 3 Overview

### 3.1 Components



Name and Function of Components	
1	Display
2	Operation keys
3	Model sticker (with approved models only)
4	Level indicator
5	Weighing pan
6	Draft shield ring / element
7	Leveling foot
8	Glass draft shield
9	Handle for operation of the draft shield door
10	Socket for AC Adapter
11	RS232C serial interface COM1
12	Kensington slot for anti-theft purposes
13	Second RS232C serial interface COM2 (JP models)
14	Product label

## 3.2 Operation Keys




### Key Functions

No.	Key	Press briefly (less than 1.5 s)	Press and hold (longer than 1.5 s)
1		<ul style="list-style-type: none"> <li>To change display resolution (1/10d function) while application is running</li> <li><b>Note:</b> not available with approved models in selected countries.</li> </ul>	no function
2		<ul style="list-style-type: none"> <li>To navigate back (scroll up) within menu topics or menu selections</li> <li>Decrease (numerical) parameters within menu and in applications</li> </ul>	<ul style="list-style-type: none"> <li>To select the weighing application</li> <li>Decrease (numerical) parameters quickly within menu and in applications</li> </ul>
3		<ul style="list-style-type: none"> <li>To navigate forward (scroll down) within menu topics or menu selections</li> <li>Increase (numerical) parameters within menu and in applications</li> </ul>	<ul style="list-style-type: none"> <li>To select assigned application and entering the parameter settings of application.</li> <li>Default application assignment: Piece counting</li> <li>Increase (numerical) parameters quickly within menu and in applications</li> </ul>
4	ON/OFF	<ul style="list-style-type: none"> <li>Switch on</li> </ul>	<ul style="list-style-type: none"> <li>Switch off</li> </ul>
5	→0/T←	<ul style="list-style-type: none"> <li>Zero/Tare</li> </ul>	<ul style="list-style-type: none"> <li>Switch off</li> </ul>
6	C	<ul style="list-style-type: none"> <li>Cancel and to leave menu without saving (one step back in the menu).</li> </ul>	no function
7		<ul style="list-style-type: none"> <li>With entries: scroll down</li> <li>To navigate through menu topics or menu selections</li> <li>To toggle between unit 1, recall value (if selected), unit 2 (if different from unit 1) and the application unit (if any)</li> </ul>	<ul style="list-style-type: none"> <li>Execute predefined adjusting (calibration) procedure</li> </ul>

No.	Key	Press briefly (less than 1.5 s)	Press and hold (longer than 1.5 s)
8		<ul style="list-style-type: none"> <li>To enter or leave menu selection (from / to menu topic)</li> <li>To enter application parameter or switch to next parameter</li> <li>To store parameter</li> </ul>	<ul style="list-style-type: none"> <li>Enter or leave menu (Parameter settings)</li> </ul>
9		<ul style="list-style-type: none"> <li>Printout display value</li> <li>Printout active user menu settings</li> <li>Transfer data</li> </ul>	

### 3.3 Display Panel



Application Icons			
	Menu locked		Application "Statistics"
	Menu setting activated		Application "Totaling"
	Application "Weighing"		Application "Multiplication factor"
	Application "Piece counting"		Application "Division factor"
	Application "Percent weighing"		Application "Density"
	Application "Check weighing"		
Status Icons			
<b>M</b>	Indicates stored value (Memory)		Service reminder
<b>Net</b>	Indicates Net weight values		Acoustic feedback for pressed keys activated
	Adjustments (calibration) started	<b>W1</b>	Weighing range 1 (Dual Range models only)
<b>FACT</b>	FACT activated	<b>W2</b>	Weighing range 2 (Dual Range models only)
	Applications "Diagnostics" and "Routine Test"		Charge of battery: full, 2/3, 1/3, discharged (Battery operated models only)
Weight Value Field and Weighing-in aid			
<b>-</b>	Indicates negative values		Brackets to indicate uncertified digits (approved models only)
<b>○</b>	Indicates unstable values		Marking of nominal or target weight
<b>*</b>	Indicates calculated values		Marking of tolerance limit T+
			Marking of tolerance limit T-

Unit Field						
GNctls%bahth msgPCStbidzt <b>kgmgm</b>	<b>g</b>	gram	<b>ozt</b>	troy ounce	<b>tls</b>	Singapore taels
	<b>kg</b>	kilogram	<b>GN</b>	grain	<b>tlt</b>	Taiwan taels
	<b>mg</b>	milligram	<b>dwt</b>	pennyweight	<b>tola</b>	tola
	<b>ct</b>	carat	<b>mom</b>	momme	<b>baht</b>	baht
	<b>lb</b>	pound	<b>msg</b>	mesghal		
	<b>oz</b>	ounce	<b>tlh</b>	Hong Kong taels		

## 4 Setting up the Balance



The balance must be disconnected from the power supply when carrying out all setup and mounting work.


### 4.1 Unpacking and Delivery Inspection

- 1 Open the packaging and carefully remove all components.
- 2 Check the delivered items.

The standard scope of delivery contains the following items:

Components		Carat balances	Gold balances		
		0.001 ct	0.001 g	0.01 g	0.1 g
Draft shield	165 mm	✓	✓	–	–
Weighing pan	Ø 90 mm	✓	–	–	–
	Ø 120 mm	–	✓	–	–
	170 x 190 mm	–	–	✓	✓
Draft shield ring		✓	–	–	–
Draft shield element		–	–	✓	–
Pan support		✓	✓	✓	✓
Bottom plate		✓	✓	–	–
Protective cover		✓	✓	✓	✓
Universal AC adapter (with plug set)		✓	✓	✓	✓
Carat pan	S 80 Ø x 20 mm	✓	–	–	–
Operating Instructions		✓	✓	✓	✓
Quick Guide		✓	✓	✓	✓
EC declaration of conformity		✓	✓	✓	✓

### 4.2 Installing the Components




#### Carat balances with readability of 0.001 ct

– Place the following components on the balance in the specified order:

**Note:** Push the side glass door (1) back as far as will go.

- Bottom plate (2)
- Draft shield element (3)
- Pan support (4)
- Weighing pan (5)




#### Gold balances with readability of 0.001 g

– Place the following components on the balance in the specified order:


**Note:** Push the side glass door (1) back as far as will go.

- Bottom plate (2)
- Pan support (3) if present
- Weighing pan (4)



#### Gold balances with readability of 0.01g

- 1 Remove the two screws (1)
- 2 Remove the plate (2) and retain it.
- 3 Place draft shield element (3) and fix it with the two screws.
- 4 Place pan support (4) with weighing pan (5).



#### Gold balances with readability of 0.1 g

– Place the following components on the balance in the specified order:


- Pan support (1)
- Weighing pan (2)

### 4.3 Selecting the Location and Leveling the Balance

Your balance is a precision instrument and will thank you for an optimum location with high accuracy and dependability.

### 4.3.1 Selecting the Location

Select a stable, vibration-free position that is as horizontal as possible. The surface must be able to safely carry the weight of a fully loaded balance.




Observe ambient conditions (see Technical Data).

Avoid the following:


- Vibrations
- Excessive temperature fluctuations
- Direct sunlight
- Powerful drafts (e.g. from fans or air conditioners)

### 4.3.2 Leveling the Balance



The balances have a level indicator and two or four adjustable leveling feet to compensate for slight irregularities in the surface of the weighing bench. The balance is exactly horizontal when the air bubble is in the middle of the level glass.

**Note:** The balance should be leveled and adjusted each time it is moved to a new location.



#### Balances with 2 leveling feet


- Adjust the two front leveling feet appropriately until the air bubble comes to rest exactly in the middle of the glass:

Air bubble at "12 o'clock"	turn both feet clockwise
Air bubble at "3 o'clock"	turn left foot clockwise, right foot counterclockwise
Air bubble at "6 o'clock"	turn both feet counterclockwise
Air bubble at "9 o'clock"	turn left foot counterclockwise, right foot clockwise

#### Balances with 4 leveling feet

- 1 First turn the two **rear** leveling feet all the way in.
- 2 Adjust the two **front** leveling feet as previously described.
- 3 Turn the **rear** leveling feet down onto the surface for extra stabilizing safety, so the balance cannot tilt over under eccentric loads.

### 4.4 Power Supply



**Allow your balance to warm up for 30 minutes (0.1 mg models 60 minutes) to enable it to adapt itself to the ambient conditions.**

## 4.4.1 AC Operation

Your balance is supplied with an country-specific AC adapter or with a country-specific power cable. The power supply is suitable for all line voltages in the range: 100 - 240 VAC, 50/60 Hz (for exact specifications, see section "technical data").




First, check the local line voltage is in the range 100 - 240 VAC, 50/60 Hz and whether the power plug fits your local power supply connection. **If this is not the case, on no account connect the balance or the AC adapter to the power supply**, but contact the responsible METTLER TOLEDO dealer.



### Important:

- Before operating, check all cables for damage.
- Guide the cables so that they cannot become damaged or interfere with the weighing process!
- Take care that the AC adapter cannot come into contact with liquids!
- The power plug must be always accessible.



Connect the AC adapter to the connection socket on the back of your balance (see figure) and to the power line.

## 4.4.2 Battery Operation

The Balance can also operate with batteries. Under normal operation conditions, the balance works independently of the AC power line for about 8 to 15 hours (using alkaline batteries). Immediately after the AC power supply is interrupted e.g. by withdrawing the power plug or if there is a power failure, the balance switches automatically to battery operation. Once the AC power supply is restored, the balance reverts automatically to AC operation.

**Note:** It is also possible to use rechargeable batteries. Charging batteries inside the balance is not possible.



battery fully



2/3 full



1/3 full



battery empty

When the balance is operating on its batteries, the battery symbol in the display lights up. The number of segments that are lit is an indicator of battery condition (3 = fully charged, 0 = discharged). When the batteries are almost completely discharged, the battery symbol flashes.

### Inserting / Replacing Batteries




The balance must be disconnected from the power supply when carrying out all setup and mounting work.





- Make sure that the balance is off before removing or inserting batteries.
- **Do not place the balance on the pan support location bolt.**
- **Battery Warnings:** Read and follow all warnings and instructions supplied by the battery manufacturer.
- Do not mix different types or brands of batteries. Performance of batteries can vary very greatly depending on the manufacturer.
- If you don't operate the balance with batteries for an extended period, it is recommended to remove the batteries from the balance.
- Batteries must be disposed of in an environmentally responsible manner. No attempt must be made to incinerate or disassemble item.

Your balance uses 8 standard AA (LR6) batteries (alkaline batteries preferred)



- 1 Remove weighing pan, pan support and draft shield element or draft shield "100 mm" if present.
- 2 Turn the balance carefully on its side.
- 3 Open and remove the battery-chamber cover.
- 4 Insert / replace the batteries with the correct polarity as shown in the battery holder.
- 5 Insert and close the battery-chamber cover.
- 6 Turn the balance carefully to its normal position.
- 7 Reinstall all components in the reverse order.

## 4.5 Transporting the Balance

Switch off the balance and remove the power cable and any interface cable from the balance. Refer to the notes in Section "Selecting the location" regarding the choice of an optimal location.

### Transporting Over Short Distances



**For balances with a draft shield:** Observe the following instructions to transport your balance over a short distance to a new location: **Never lift the balance using the glass draft shield. The draft shield is not sufficiently fastened to the balance.**

### Transporting Over Long Distances

If you would like to transport or send your balance over long distances, **use the complete original packaging.**


## 4.6 Weighing Below the Balance

The balances are equipped with a hanger for carrying out weighings below the work surface (weighing below the balance).



### Attention:

- **Do not place the balance on the pan support location bolt.**



- 1 Switch off the balance and remove the power cable and any interface cable from the balance.
- 2 Remove weighing pan, pan support and draft shield element or "Easy draft shield" if present.
- 3 Turn the balance carefully on its side.
- 4 Remove one of the caps (A) depending on the models.
- 5 Then turn the balance to its normal position and simply reinstall all components in the reverse order.

## 4.7 Adjustment (Calibration)



### To obtain accurate weighing results,

- the balance must be adjusted to match the gravitational acceleration at its location. Adjusting is necessary:
  - before the balance is used for the first time.
  - at regular intervals during weighing service.
  - after a change of location.
- the balance must be connected to the power supply for approximately,
  - 30 minutes for balances with readability of 0.01 ct / 0.001 g to 0.1 g
  - 60 minutes for balances with readability of 0.0001 ct / 0.01 mg to 0.001 ct / 0.1 mg
 in order to reach operating temperature before adjusting.

### 4.7.1 Fully Automatic Adjustment FACT

**Note:** On models with FACT only.


The **factory setting** is fully automatic adjustment **FACT** (Fully Automatic Calibration Technology) with the internal weight (see also section "The Menu"). In this setting, you have no need worry about adjusting your balance.

The balance adjusts itself automatically:

- after the warm-up phase on connection to the power supply.
- when a change in the ambient conditions, e.g. the temperature, could lead to a noticeable deviation in the measurement.
- on a predefined time. (see menu topic "FACT")
- time interval. (with OIML accuracy class II approved models)

### 4.7.2 Adjustment with Internal Weight

**Note:** On models with internal weight only (see technical data).



**Requirement:** To carry out this operation, in the menu topic "CAL" (Adjustment) of advanced menu "ADJ.INT" must be selected.

- 1 Unload weighing pan
- 2 Press and hold «» to execute "Internal Adjustment".

The balance adjusts itself automatically. The adjusting is finished when the message "ADJ.DONE" appears briefly on the display. The balance returns to the last active application and is ready for operation.


### Sample adjustment printout using internal weight:

```
- Internal Adjustment --  
21.Jan 2010      12:56  
  
METTLER TOLEDO  
  
Balance Type     JP4002G  
SNR              1234567890  
  
Temperature      22.5 °C  
Diff             3 ppm  
  
Adjustment done  
-----
```


### 4.7.3 Adjustment with External Weight

**Note:** Because of certification legislation, the approved models cannot be adjusted with an external weight \* (depend on selected countries' certification legislation).

\* except OIML accuracy class I approved models.



**Requirement:** To carry out this operation, in the menu topic "CAL" (Adjustment) " of advanced menu ADJ.EXT" must be selected.

- 1 Have required adjustment weight ready.
- 2 Unload weighing pan.
- 3 Press and hold «» to execute "External Adjustment". The required (predefined) adjustment weight value flashes in the display.
- 4 Place adjustment weight in center of pan. The balance adjusts itself automatically.
- 5 When "0.00 g" flashes, remove adjustment weight.

The adjusting is finished when the message "ADJ.DONE" appears briefly on the display. The balance returns to the last active application and is ready for operation.

**Sample adjustment printout using external weight:**

```
- External Adjustment --  
21.Jan 2010          12:56  
  
METTLER TOLEDO  
  
Balance Type      JP4002G  
SNR               1234567890  
  
Temperature       22.5 °C  
Nominal           2000.00 g  
Actual            1999.99 g  
Diff              5 ppm  
  
Adjustment done  
  
Signature  
  
.....  
-----
```


## 5 Weighing Made Simple



This section shows you how to perform simple weighings and how you can accelerate the weighing process.

### 5.1 Switching the Balance On and Off

This section shows you how to perform simple weighings and how you can accelerate the weighing process.




#### Switching On

- 1 Remove any load from weighing pan.
- 2 Press «On».


The balance performs a display test (all segments in the display light up briefly), "WELCOME", Software version, Maximum load and Readability appears briefly. (Startup "FULL" mode only)

The balance is ready for weighing or for operation with the last active application.



#### Switching Off

- Press and hold the «Off» key until "SHUTOFF" appears on the display. Release the key.




**When Quickstart is selected** (Advanced menu, topic "STARTUP" > "QUICK"): Once your balance has been switched off, it is in standby mode. In this case your balance needs no warm-up time in the standby mode and is immediately ready for weighing. If you wish to perform a weighing, you now only need to place the sample on the weighing pan and the balance immediately displays the result. There is no need to switch it on with the «On/Off» key.

- If your balance has been switched off after a preselected time, the display is dimly lit and shows date, time, maximum load and readability.
- If your balance has been switched off manually, the display is off.

#### Note:


- Quickstart is not possible with approved balances (only available in selected countries).
- Standby mode is available on line powered balances only.

## 5.2 Performing a Simple Weighing



- 1 Press «→0/T←» to zero the balance.  
**Note:** If your balance is not in the weighing mode, first press and hold the « $\Delta\Delta$ » key until "WEIGH" appears in the display. Release the key. Your balance is in the weighing mode.
- 2 Place weighing sample on the weighing pan.
- 3 Wait until the instability detector "O" disappears and the stability beep sounds.
- 4 Read the result.


## 5.3 Zero Setting / Taring



### Zero setting

- 1 Unload the balance.
- 2 Press «→0/T←» to set the balance to zero. All weight values are measured in relation to this zero point (see menu topic "ZERO.RNG").

**Note:** Use the «→0/T←» zeroing key before you start with a weighing.



### Taring

If you are working with a weighing container, first set the balance to zero.


- 1 Place empty container on the balance. The weight is displayed.
- 2 Press «→0/T←» to tare the balance.

"0.00 g" and "Net" appears in the display. "Net" indicates that all weight values displayed are net values.

### Note:

- If the container is removed from the balance, the tare weight will be shown as a negative value.
- The tare weight remains stored until the «→0/T←» key is pressed again or the balance is switched off.

## 5.4 Switching Weight Units




The « $\curvearrowright$ » key can be used at any time to toggle between weight unit "UNIT 1", "RECALL" value (if selected), weight unit "UNIT 2" (if different from weight unit 2) and the application unit (if any).

## 5.5 Recall / Recall Weight Value

Recall stores stable weights with an absolute display value bigger than 10d.

**Requirement:** The function "RECALL" must be activated in the menu.




- 1 Load weighing sample. The display shows weight value and stores stable value.
- 2 Remove weighing sample. When the weight is removed the Display shows zero.
- 3 Press «←». The display shows last stored stable weight value for 5 seconds together with asterisk (\*) and Memory (M) symbols. After 5 seconds the display goes back to zero. This can be repeated unlimited times.

### Delete last weight value

As soon a new stable weight value is displayed, the old recall value becomes replaced by the new weight value. When pressing «→0/T←», the recall value is set to 0.


**Note:** If the power is switched off, the recall value is lost. The recall value can not be printed.


## 5.6 Weighing with the Weighing-in Aid



The weighing-in aid is a dynamic graphic indicator which shows the used amount of the total weighing range. You can thus recognize at a glance whether the load on the balance approaches the maximum load.

## 5.7 Print / Transmit Data



Pressing the «» key transmits the weighing results over the interface e.g. to a printer or a PC.

## 6 The Menu

### 6.1 What is in the Menu ?



The Menu allows you to match your balance to your specific weighing needs. In the menu you can change the settings of your balance and activate functions. The main menu has 4 different menus and these contains 34 different **topics**, each of which allows you various **selection** possibilities. For Menu "PROTECT" see chapter "Description of menu topics" section "Main menu".

**Note:** See Quick Guide for the graphical overview of the menu (Menu Map) with all setting possibilities.

#### Menu "BASIC"

Topic	Description
DATE	Setting the current date.
TIME	Setting the current time.
UNIT 1	Specification of the 1 <sup>st</sup> weight unit in which the balance should show the result.
UNIT 2	Specification of the 2 <sup>nd</sup> weight unit in which the balance should show the result.
KEY.BEEP	Setting the key beep level.
STB.BEEP	Setting the stability beep level.
RESET	Call up of the factory settings.

#### Menu "ADVANCE."

Topic	Description
ENVIRON.	Matching the balance to the ambient conditions.
CAL	Settings for the type of adjustment (calibration).
FACT	Settings for fully automatic balance adjustment based on a selected time.
FACT PRT	Switching the automatic FACT printout on or off.
DATE.FRM	Setting the date format.
TIME.FRM	Preselection of the time format.
RECALL	Switching the application "Recall" for storing stable weights on or off.
STARTUP	Setting the mode which the balance powers up ("FULL" or "QUICK").
SHUTOFF	Setting the time after which the balance should be switched off automatically.
B.LIGHT	Setting the time after which the display backlight should be switched off automatically.
A.ZERO	Switching the automatic zero correction (Autozero) on or off.
ZERO.RNG	Setting the zero limit of the zero/tare key.
ASSIGN:F	Selection of assigned F key application and entering their parameter settings.
DIAGNOS.	Starting a diagnostic application.
SRV.ICON	Switching the service reminder (service icon) on or off.
SRV.D.RST	Reset service date and hours (service reminder)

#### Menu "INT.FACE"


Topic	Description
RS232	Matching the serial interface RS232C to a peripheral unit.
HEADER	Setting the header for printout of individual values.
SINGLE	Setting the information for printout of individual values.
SIGN.L	Setting the footer for printout of individual values.
LN.FEED	Setting line feed for printout of individual values.
ZERO.PRT	Setting the auto print function for printing zero.
COM.SET	Setting the data communication format of the serial interface RS232C.
BAUD	Setting the transfer speed of the serial interface RS232C.
BIT.PAR.	Setting the character format (Bit/Parity) of the serial interface RS232C.
STOPBIT	Setting the character format (stop bit) of the serial interface RS232C.
HD.SHK	Setting the transfer protocol (Handshake) of the serial interface RS232C.
RS E.O.L.	Setting the end of line format of the serial interface RS232C.



Topic	Description
RS.CHAR	Setting the char set of the serial interface RS232C.
INTERVL.	Selection of the time interval for the simulated print key press.

## 6.2 Menu Operation


In this Section you will learn how to work with the menu.



### Select Menu


- 1 Press and hold «⚙» to activate main menu. The first menu "BASIC" is displayed (except menu protection is active).
- 2 Press «↻» repeatedly to change menu (Scrolling down/up «+» / «-» keys).
- 3 Press «⏏» to confirm the selection.

**Note:** The menu selection "BASIC", "ADVANCE." or "INT.FACE" can not be saved. The selection "PROTECT" must be saved.



### Select Menu Topic

- Press «↻». The next menu topic appears in the display. Each time the «↻» or the «+» key is pressed, the balance switches to the next menu topic; the «-» key to the previous menu topic.




### Change Settings in a Selected Menu Topic

- 1 Press «⏏». The display shows the current setting in the selected menu topic. Each time «↻» or «+» is pressed, the balance switches to the next selection; press «-» to the previous selection. After the last selection, the first is shown again.
- 2 Press «⏏», the selected setting is accepted but not yet executed. The settings are executed only after "SAVE:YES" has been confirmed.


### Change Settings in a Submenu Selection

The same procedure as for menu topics.







### Input Principle of Numerical Values

- 1 Press «⏏» for input of numerical values.
- 2 Press «↻» to select a digit or a value (depending on the application). The selected digit or the selected value is blinking.
- 3 For changing digits or values, press «+» to scroll up or «-» to scroll down.
- 4 Press «⏏» to confirm the input.




### Saving Settings and Closing the Menu

- 1 Press and hold «» to leave menu topic.
- 2 Press «» to execute "SAVE:YES". Changes are saved.
- 3 Press «» to execute "SAVE:NO". Changes are not saved. To toggle between "SAVE:YES" and "SAVE:NO" press «».



### Cancel

- For leaving menu topic or menu selection without saving press «» (one step back in the menu).


**Note:** If no entry is made within 30 seconds, the balance reverts to last active application mode. Changes are not saved. If changes are made, the balance asks "SAVE:NO".

## 6.3 Description of Menu Topics

In this Section you will find information regarding the individual menu topics and the available selections.

### 6.3.1 Main Menu

Selecting the menu.

"BASIC"	The small "BASIC" menu for simple weighing is displayed.
"ADVANCE."	The extended "ADVANCE." menu for further weighing settings is displayed.
"INT.FACE"	The menu "INT.FACE" for all interface parameter settings for peripheral devices e.g. printer is displayed.
"PROTECT"	Menu protection. Protection of balance configurations against unmeant manipulation.
"OFF"	Menu protection is off. ( <b>Factory setting</b> )
"ON"	Menu protection is on. The menu BASIC, ADVANCE. and INT.FACE are not displayed. This is indicated with "  " in the display.

**Note:**

- The menu selection "BASIC", "ADVANCE." or "INT.FACE" can not be saved.
- To activate "PROTECT" "ON" or "OFF", this selection must be saved.

### 6.3.2 Basic Menu

#### "DATE" – Date

Setting the current date according to date format.

**Note:** A reset of the balance will not change this setting.

#### "TIME" – Time

Setting the current time according to time format

"+1H"	Set the current time forwards by 1 hour (to adjust summer or winter time). ( <b>Factory setting</b> )
"-1H"	Set the current time backwards by 1 hour (to adjust summer or winter time).
"SET.TIME"	Enter the current time.

**Note:** A reset of the balance will not change this setting.

## "UNIT 1" – Weight Unit 1

Depending on requirements, the balance can operate with the following units (depending on the model)

- Only those weight units allowed by the appropriate national legislation are selectable.
- With approved balances, this menu topic has a fixed setting and cannot be changed.
- Conversion table for weight units see chapter Appendix.

### Units:

<b>g</b> <sup>1)</sup>	Gram	<b>dwt</b>	Pennyweight
<b>kg</b> <sup>3)</sup>	Kilogram	<b>mom</b>	Momme
<b>mg</b> <sup>4)</sup>	Milligram	<b>msg</b>	Mesghal
<b>ct</b> <sup>2)</sup>	Carat	<b>tlh</b>	Tael Hong Kong
<b>lb</b>	Pound	<b>tls</b> <sup>5)</sup>	Tael Singapore
<b>oz</b>	Ounce (avdp)	<b>tit</b>	Tael Taiwan
<b>ozt</b>	Ounce (troy)	<b>tola</b>	Tola
<b>GN</b>	Grain	<b>baht</b>	Baht

1) factory setting for gold balances

2) factory setting for carat balances

3) not with 0.1 mg and 1 mg balances

4) with 0.1 mg and 1 mg balances

5) the Malaysian tael has the same value

## "UNIT 2" – Weight Unit 2

If it is required to show the weighing results in weighing mode in an additional unit, the desired second weight unit can be selected in this menu topic (depending on the model). Units see "UNIT 1".

**Note:** Only those weight units allowed by the appropriate national legislation are selectable.

## "KEY.BEEP" – Key Beep

This menu topic allows you to select the volume of the key beep. The according key beep is emitted during the setting.

"MED"	<b>Medium</b> level ( <b>Factory setting</b> )
"HIGH"	<b>High</b> level
"OFF"	Beep switched off
"LOW"	<b>Low</b> level

## "STB.BEEP" – Stability Beep

If the unstable symbol disappears, the stability beep becomes active. This menu topic allows you to preselect the volume of the stability beep.

"LOW"	<b>Low</b> level ( <b>Factory setting</b> )
"MED"	<b>Medium</b> level
"HIGH"	<b>High</b> level
"OFF"	Beep switched off

## "RESET" – Reset Balance Settings

This menu topic allows you to cal-up the factory settings.

To toggle between "YES?" and "NO?" press  (or «+» or «-»).

**Note:** A reset of the balance will not change the "DATE" and "TIME" settings.



### 6.3.3 Advanced Menu


#### "ENVIRON." – Environment Settings

This setting can be used to match your balance to the ambient conditions.

"STD."	Setting for an average working environment subject to moderate variations in the ambient conditions. ( <b>Factory setting</b> )
"UNSTAB."	Setting for a working environment where the conditions are continuously changing.
"STABLE"	Setting for a working environment which is practically free from drafts and vibrations.

#### "CAL" – Adjustment (calibration)

In this menu topic you can preselect the function of the «» key. Your balance can be adjusted with internal or external weights by pressing the «» key. If you have attached a printer to your balance, the data of the adjustment (calibration) are printed out.

"ADJ.OFF"	The adjustment is <b>switched off</b> . The «  » key has no function.
"ADJ.INT"	<b>Internal</b> adjustment: adjustment is performed at a keystroke with the built-in weight (depending on the model, see technical data).
"ADJ.EXT"	<b>External</b> adjustment: adjustment is performed at a keystroke with a selectable external weight. <b>Note:</b> This function is not available for approved balances * (depend on selected countries' certification legislation). * except OIML accuracy class I approved models.
"200.00 g"	<b>Defining the external adjustment weight:</b> define the weight of the external adjustment weight (in grams). <b>Factory setting:</b> depends on the model.

#### "FACT" – Fully Automatic Adjustment

Fully automatic internal adjustment (calibration) **FACT** (Fully Automatic Calibration Technology) provides fully automatic balance adjustment based on temperature criteria and on preselected time. (depending on the model, see technical data)

"TIME"	Execute FACT (with selected time).
"12:00"	Specify the time for a fully automatic adjustment to take place every day. <b>Factory setting:</b> 12:00 (according to time format)
"OFF"	FACT is <b>switched off</b> .

#### "FACT.PRT" – Protocol Trigger for Fact

This setting specifies whether an adjustment report should be printed automatically.

**Note:** This menu topic does not affect the printing of adjustments with an internal or external adjustment weight.

"OFF"	<b>Protocol switched off:</b> if the balance adjusts automatically (FACT), a protocol is not printed out.
"ON"	Protocol switched on: a record is printed out after every automatic adjustment of the balance (FACT). <b>Note:</b> The protocol is printed out without a line for signatures.

#### "DATE.FRM" – Date Format

This menu topic allows you to preselect the date format.

The following date formats are available:

	Display examples	Printing examples
"DD.MM.Y"	01.02.09	01.02.2009

"MM/DD/Y"	02/01/	02/01/2009
"Y-MM-DD"	-02-01	2009-02-01
"D.MMM Y"	1.FEB.09	1.FEB 2009
"MMM D Y"	FEB.1.09	FEB 1 2009

**Factory setting:** "DD.MM.Y"

#### "TIME.FRM" – Time Format

This menu topic allows you to preselect the time format.

The following date formats are available:

	Display examples
"24:MM"	15:04
"12:MM"	3:04 PM
"24.MM"	15.04
"12.MM"	3.04 PM

**Factory setting:** "24:MM"

#### "RECALL" – Recall

This menu topic allows you to switch the "RECALL" function on or off. When it is switched on recall stores the last stable weight if the absolute display value was bigger than 10d.

"OFF"	"RECALL" switched off ( <b>Factory setting</b> )
"ON"	"RECALL" switched on

**Note:** The recall value is displayed with an asterisk and cannot be printed.

#### "STARTUP" – Startup Mode

You can set your balance such that it either immediately starts from the standby mode when you load a weight or it must be switched on with the «ON/OFF» key after which it then performs a display test.

**Note:** This topic is not visible with approved balances (only available in selected countries).

"QUICK"	<b>"Quickstart":</b> The balance can be started directly from the standby mode and is immediately ready for weighing. You can load the weight in the standby mode and the balance immediately shows the current weighing result. This is the <b>Factory setting</b> <b>Note:</b> Standby mode is available on line powered balances only.
"FULL"	<b>Start with display test:</b> You must switch on the balance with the «ON/OFF» key. After it has been switched on, it performs a display test for approx. 2 sec. in which all display elements lights up, it shows "WELCOME", software version, maximum load and readability. The balance is ready for weighing.

#### "SHUTOFF" – Automatic Shutoff

If the automatic shutoff function is activated, the balance automatically switches itself off after a preselected time of inactivity (i.e. with no key being pressed or changes of weight occurring etc.) and is switched to the standby mode.

"A.OFF:10' "	Automatic shutoff after <b>10 minutes</b> of inactivity. ( <b>Factory setting</b> )
"A.OFF – "	Automatic shutoff <b>not</b> activated.
"A.OFF:2' "	Automatic shutoff after <b>2 minutes</b> of inactivity.
"A.OFF:5' "	Automatic shutoff after <b>5 minutes</b> of inactivity.

### "B.LIGHT" – Backlight

Under this menu topic, the display backlight can be switched off automatically. If the automatic switch-off is activated, the backlight will turn off automatically after the selected period of inactivity has elapsed. The backlight is reactivated when a key is pressed or the weight is changed.

"B.L. ON"	Backlight is always <b>on</b> . ( <b>Factory setting</b> )
"B.L. OFF"	Backlight is always <b>off</b> .
"B.L. 30" "	Automatic switch-off after <b>30 seconds</b> inactivity.
"B.L. 1' "	Automatic switch-off after <b>1 minute</b> inactivity.
"B.L. 2' "	Automatic switch-off after <b>2 minutes</b> inactivity.
"B.L. 5' "	Automatic switch-off after <b>5 minutes</b> inactivity.

### "A.ZERO" – Automatic Zero Setting

This menu topic allows you to switch the automatic zero setting on or off.

"ON"	"A.ZERO" <b>switched on</b> (factory setting). The automatic zero setting continuously corrects possible variations in the zero point that might be caused through small amounts of contamination on the weighing pan.
"OFF"	"A.ZERO" <b>switched off</b> . The zero point is not automatically corrected. This setting is advantageous for special applications (e.g. evaporation measurements).

**Note:** With approved balances, this setting is not available (only available in selected countries).

### "ZERO.RNG" – Zero Range

This menu topic allows you to set a zero limit for the «→0/T←» key. Up to and including this limit the «→0/T←» key will execute a zero. Above this limit the «→0/T←» key will execute a tare.

"21g"	To set the upper limit of the zeroing range as weight in the definition unit of the balance. ( <b>Factory setting:</b> 0.5% of weighing range)
-------	---

**Note:** With approved balances, this setting is not available and fixed to 3e (only available in selected countries).

**Note:** A reset of the balance will not change this setting.

### "ASSIGN:F" – Assign Application Key F

At this menu topic you can assign an application to the «F» key. The following applications are available (depending on the model):

"COUNT"	Piece counting ( <b>Factory setting</b> )
"PERCENT"	Percent weighing
"CHECK"	Checkweighing
"STAT"	Statistics
"TOTAL"	Totaling
"FACTOR.M"	Multiplication factor
"FACTOR.D"	Division factor
"DENSITY"	Density (not available with JS models)
"R.TEST"	Routine test

### "DIAGNOS." – Diagnostics Application

At this menu topic you can start a diagnostic application. For more information see chapter application "Diagnostics".

The following diagnostics are available:

"REPEAT.T"	Repeatability test (models with internal weights only)
"DISPLAY"	Display test
"KEYPAD.T"	Key test
"CAL.MOT.T"	Motor test (models with internal weights only)
"BAL.HIST"	Balance history
"CAL.HIST"	Calibration history
"BAL.INFO"	Balance information
"SRV.PROV"	Service provider information

#### "SRV.ICON" – Service Reminder


This menu topic allows you to switch the service reminder "🔧" on or off.

"ON"	Service reminder "🔧" <b>switched on</b> . You will be informed after one Year or 8000 operating hours to call service for recalibration. This will be indicated by the flashing service icon: "🔧". <b>(Factory setting)</b>
"OFF"	Service reminder "🔧" <b>switched off</b> .

#### "SRV.D.RST" – Service Date Reset

This menu topic allows you to reset service date and hours.







**Note:** This menu topic is only available if "SRV.ICON" setting "ON" was selected.





To toggle between "YES?" and "NO?" press «» (or «+» or «-»)

### 6.3.4 Interface Menu

#### "RS232" – RS232C Interface <sup>1)</sup>

At this menu topic you can select the peripheral device connected to the RS232C interface and specify how the data is transmitted.

"PRINTER"	Connection to a <b>printer</b> . <b>(Factory setting)</b> <b>Note:</b> <ul style="list-style-type: none"> <li>• Only one printer possible.</li> <li>• See recommended printer settings found in section "Appendix", as well as the printer-specific user's manual.</li> </ul>
"PRT.STAB"	If the «  » key is pressed, the next stable weight value will be printed. <b>(Factory setting)</b>
"PRT.AUTO"	Every stable weight value will be printed, without pressing the «  » key.
"PRT.ALL"	If the «  » key is pressed, the weight value will be printed regardless of stability.
"PC-DIR."	Connection to a <b>PC</b> : the balance can send data (as a Keyboard) to the PC used for PC applications e.g. Excel. <b>Note:</b> The balance sends the weight value without the unit to the PC.
"PRT.STAB"	If the «  » key is pressed, the next stable weight value will be sent followed by an enter. <b>(Factory setting)</b>
"PRT.AUTO"	Every stable weight value will be sent followed by an enter, without pressing the «  » key.
"PRT.ALL"	If the «  » key is pressed, the weight value will be sent followed by an enter regardless of stability.


"HOST"	Connection to a <b>PC</b> , Barcode Reader etc.: the balance can send data to the PC and receive commands or data from the PC. <b>Note:</b> The balance sends the complete MT-SICS answer to the PC (see chapter "MT-SICS Interface Commands and Functions").
"SND.OFF"	Send mode switched off. ( <b>Factory setting</b> )
"SND.STB"	If the «  » key is pressed, the next stable weight value will be sent.
"SND.CONT"	All weight value updates will be sent regardless of stability, without pressing the «  » key.
"SND.AUTO"	Every stable weight value will be sent, without pressing the «  » key.
"SND.ALL"	If the «  » key is pressed, the weight value will be sent regardless of stability.
"2.DISP"	Connection of an <b>optional auxiliary display</b> unit. <b>Note:</b> The transmission parameters cannot be selected. Settings are automatically set.



**Attention:** If you select 2nd Display "2.DISP", first make sure that no other device is connected at COM1 as an auxiliary display. Other devices could be damaged because of the voltage on connector Pin 9. Necessary for powering the display (see Chapter "Interface Specification").

- The second interface COM2 if present, has no power supply for a 2nd display. Connect it preferably on COM1.

#### "HEADER" – Options for the Printout Header of individual values


This menu topic allows you to specify the information that is to be printed at the top of the printout for every individual weighing results (after pressing «»).

**Note:** This menu topic is only available if "PRINTER" setting was selected.

"NO"	The header is not be printed ( <b>Factory setting</b> )
"DAT/TIM"	Date and time are printed
"D/T/BAL"	Date, time and balance information (Balance type, SNR, Balance ID) are printed.

**Note:** Balance ID only if set.


#### "SINGLE" – Options for Printing out the Result of individual values

This menu topic allows you to specify the information that is to be printed for every individual weighing result (after pressing «»).

**Note:** This menu topic is only available if "PRINTER" setting was selected.

"NET"	The value of the Net weight from the current weighing is printed ( <b>Factory setting</b> )
"G/T/N"	The values of the Gross weight, the Tare weight and the Net weight are printed

#### "SIGN.L" – Options for the Printout Footer for Signature Line of individual values


This menu topic allows you to set a footer for signature at the bottom of the printout for every individual weighing result (after pressing «»).

**Note:** This menu topic is only available if "PRINTER" setting was selected.

"OFF"	The signature footer is not be printed. ( <b>Factory setting</b> )
"ON"	The signature footer is printed



### "LN.FEED" – Options for Complete the Printout of individual values

This menu topic allows you to specify the number of blank lines to complete the printout (line feed) for every individual weighing result (after pressing «»).

**Note:** This menu topic is only available if "PRINTER" setting was selected.

"0" Possible numbers of blank lines: 0 to 99 (**Factory setting = 0**)

### "ZERO.PRT" – Options for "PRT.AUTO" 1)

This menu topic allows you to specify the auto print function "PRT.AUTO" for printing zero "YES" or "NO".

"OFF" Zero is not be printed (Zero +/- 3d) (**Factory setting**)

"ON" Zero is always printed

**Note:** This menu topic is only available if "PRT.AUTO" fuction of the "PRINTER" or "PC-DIR." was selected.

### "COM.SET" – Options for the Data Communication Format (RS232C)("HOST")

This menu topic allows you to set the data format depending on which peripheral device is connected.

**Note:** This menu topic is only available if "HOST" setting was selected.

"MT-SICS" The MT-SICS data transfer formats is used. (**Factory setting**)  
For more information see section "MT-SICS Interface Commands and Functions".

"MT-PM" The following PM balance commands are supported:

- S Send value
- SI Send immediate value
- SIR Send immediate value and repeat
- SR Send value and repeat
- SNR Send next value and repeat
- T Tare
- TI Tare immediately
- B Base (Negative values are limited up to the current tare values)
- MI Modify ambient vibration
- MZ Modify Auto Zero
- M Modified settings reset
- ID Identify
- CA Calibrate
- D Display (only symbol N and G available)

"SART" The following Sartorius commands are supported:

- K Ambient conditions: very stable
- L Ambient conditions: stable
- M Ambient conditions: unstable
- N Ambient conditions: very unstable
- O Block keys
- P Print key (print, auto print; activate or block)
- Q Acoustic signal
- R Unblock keys
- S Restart/self-test
- T Tare key
- W Calibration/adjustment (depending on the menu setting\*)

Z	Internal calibration/adjustment **)
f0_	Function key (F)
f1_	Function key (CAL)
s3_	C key
x0_	Perform internal calibration **)
x1_	Print balance/scale model
x2_	Print weighing cell serial number
x3_	Print software version

\*) may be inaccessible on verified balances/scales

\*\*) only on models with built-in motorized calibration weight

#### Functionality mapping

"HOST" settings:	Sartorius printer settings:
"SND.OFF"	not applicable
"SND.STB"	manually print with stability
"SND.ALL"	manually print without stability
"SND.CONT"	automatically print without stability
"SND.AUTO"	similar applicable to automatically print when load is changed

#### "BAUD" – Baud rate RS232C 1)

This menu topic allows you to match the data transmission to different serial RS232C receivers. The baud rate (data transfer rate) determines the speed of transmission via the serial interface. For problem-free data transmission the sending and receiving devices must be set at the same value.

The following settings are available:

600 bd, 1200 bd, 2400 bd, 4800 bd, 9600 bd, 19200 and 38400 bd. (default: **9600 bd**)

#### Note:

- Not visible for 2nd display.
- Each device has separate settings.

#### "BIT.PAR." – Bit/Parity RS232C 1)

At this menu topic you can set the character format for the attached RS232C serial peripheral device.

"8/NO"	8 data bits/no parity ( <b>Factory setting</b> )
"7/NO"	7 data bits/no parity
"7/MARK"	7 data bits/mark parity
"7/SPACE"	7 data bits/space parity
"7/EVEN"	7 data bits/even parity
"7/ODD"	7 data bits/odd parity

#### Note:

- Not visible for 2nd display.
- Each device has separate settings.

#### "STOPBIT" – Stop Bits RS232C 1)

At this menu topic you can set the stop bits of the transmitted data to different RS232C serial receivers.

"1 BIT"	1 Stop bit ( <b>Factory setting</b> )
"2 BITS"	2 Stop bits

#### Note:

- Not visible for 2nd display.
- Each device has separate settings.

#### "HD.SHK" – Handshake RS232C <sup>1)</sup>

This menu topic allows you to match the data transmission to different RS232C serial receivers.

"XON.XOFF"	Software handshake (XON/XOFF) ( <b>Factory setting</b> )
"RTS.CTS"	Hardware handshake (RTS/CTS)
"OFF"	No handshake

#### Note:

- Not visible for 2nd display.
- Each device has separate settings.

#### "RS E.O.L." – End of Line RS232C <sup>1)</sup>

At this menu topic you can set the "End of Line" character of the transmitted data to different RS232C serial receivers.

"CR LF"	<CR><LF> Carriage Return followed by Line feed (ASCII-Codes 013+010) ( <b>Factory setting</b> )
"CR"	<CR> Carriage Return (ASCII-Code 013)
"LF"	<LF> Line feed (ASCII-Code 010)

#### Note:

- Not visible for 2nd display.
- Each device has separate settings.

#### "RS.CHAR" – Char Set RS232C <sup>1)</sup>


At this menu topic you can set the "Character Set" of the transmitted data to different RS232C serial receivers.

"IBM.DOS"	Char Set <b>IBM/DOS (Factory setting)</b>
"ANSI.WIN"	Char Set <b>ANSI/WINDOWS</b>

#### Note:

- Not visible for 2nd display.
- Each device has separate settings.

#### "INTERVL." – Print Key Simulation

At this menu topic you can activate a simulation of the «» key. "INTERVL." simulates a print key press every x seconds.

Range:	0 to 65535 seconds
0 sec:	disables the print key simulation

**Factory setting:** 0 sec


**Note:** The executed action is according to the configuration of the print key. (see interface setting)

### 1) Note for 2nd RS232C Interface (COM2)

- If a second interface is installed, the menu topic is displayed for each interface, e.g  
 "BAUD.1" for standard interface (COM1)  
 "BAUD.2" for 2nd interface (COM2)
- Only one printer can be set if two RS232 interfaces are existing.

## 7 Applications

### 7.1 Application "Piece Counting"




The "Piece Counting" application allows you to determine the number of pieces put on the weighing pan.

**Requirement:** The function "COUNT" must be assigned to the «F» key (see advanced menu topic "ASSIGN:F", factory setting).




- Activate function "COUNT" by pressing and holding the «F» key.







**Piece Counting first requires the setting of a reference weight, there are 4 possibilities:**


- A** Setting the reference **by multiple pieces with fix reference values.**
- B** Setting the reference **by multiple pieces with variable reference values.**
- C** Setting the reference **for 1 piece in weighing mode.**
- D** Setting the reference **for 1 piece in manual mode.**



Setting possibility






#### **A** Setting the reference by multiple pieces


- 1 Select a number of reference pieces by scrolling with «». Possible numbers\* are 5, 10, 20 and 50.  
\* with approved balances in selected countries: min 10
- 2 Press «0/T» to tare. If needed: place empty container on the weighing pan and tare again.
- 3 Add the selected number of reference pieces to container.
- 4 Press «» to confirm.



Setting possibility

#### **B** Setting the reference by multiple pieces with variable reference values

- 1 Select "VAR.REF" by scrolling with «». Press «» to confirm.
- 2 Select a number of reference pieces by scrolling up («+» key) or down («-» key). Speed up by press and hold. Possible numbers\* are 1 to 999.  
\* with approved balances in selected countries: min 10
- 3 Press «0/T» to tare. If using: place empty container on the weighing pan first or tare again.
- 4 Add the selected number of reference pieces to container.
- 5 Press «» to confirm.




Setting possibility

### C Setting the reference for one piece in weighing mode

- 1 Select "PCS.WGT" by scrolling with «↶↷».
- 2 Press «→0/T←» to tare. If needed: place empty container on the weighing pan and tare again.
- 3 Add one reference piece to container. The weight of one piece is displayed.
- 4 Press «←» to confirm.

**Note:** With approved balances, this setting is not available in selected countries.




Setting possibility

### D Setting the reference for one piece in manual mode

- 1 Select "PCS.WGT" by scrolling with «↶↷».
- 2 Press «←» to confirm.
- 3 Enter the final reference one piece weight by scrolling up («+» key) or down («-» key). Speed up by press and hold.
- 4 Press «←» to confirm.

**Note:** With approved balances, this setting is not available in selected countries.




### Switching between manual mode and weighing mode

- Press «←» to switch between manual and weighing mode.

**Note:** By switching from weighing mode to manual mode the weight value will be transferred and can be changed manually.

**Note:** If without any key press within 60 seconds, the balance returns to the previous active application. Press «C» to cancel and returns to the previous active application.

**On completion of the setting procedure, your balance is ready for piece counting.**



### Switching between piece count and weight display.

You can use the «←» key at any time to switch the display between piece display, weighing unit "UNIT 1", "RECALL" value (if activated) and weighing unit "UNIT 2" (if different from "UNIT 1").

**Note:**

- The "RECALL" value is displayed with an asterisk (\*) and icon "M" and can not be printed.
- Take into account minimum values: min. reference weight = 10d (10 digits), min. piece weight\* = 1 d (1 digit)!  
\* with approved balances in selected countries: min 3e
- The current reference weight remains stored until the reference setting is changed.

## 7.2 Application "Percent Weighing"




The "Percent Weighing" application allows you to check a sample weight as percentage to a reference target weight.

**Requirement:** The function "PERCENT" must be assigned to the «F» key (see advanced menu topic "ASSIGN:F").




- Activate function percent weighing "PERCENT" by pressing and holding the «F» key.



**Percent Weighing first requires the setting of a reference weight that should corresponds to 100%, there are 2 possibilities:**


- A** Setting the reference in manual mode (enter 100%).
- B** Setting the reference in weighing mode (weigh 100%).



Setting possibility

### **A** Setting the reference by manual mode (enter 100%)


- 1 Press «←» to activate manual mode.
- 2 Select the reference target weight (100%) by scrolling up («+» key) or down («-» key). Speed up by press and hold.
- 3 Press «←» to confirm.



Setting possibility

### **B** Setting the reference by weighing mode (weigh 100%)

- 1 Press «→0/T←» to tare the balance and to activate the weighing mode. If needed: place empty container on the weighing pan and tare again.
- 2 Load the reference weight (100%).  
**Note:** Reference weight must be at least +/- 10d.
- 3 Press «←» to confirm.




### **Switching between manual mode and weighing mode**

- Press «↺» to switch between manual and weighing mode.

**Note:** By switching from weighing mode to manual mode the weight value will be transferred and can be changed manually.

**Note:** If without any key press within 60 seconds, the balance returns to the previous active application.

**On completion of the weighing-in procedure, your balance is ready for percent weighing.**




### Switching between percent and weight display

You can use the «↔» key at any time to switch the display between percent display, weighing unit "UNIT 1", "RECALL" value (if activated) and weighing unit "UNIT 2" (if different from UNIT 1).

#### Note:


- The recall value is displayed with an asterisk (\*) as well as icon "M" and can not be printed.
- The current set weight remains stored until it is redetermined.

## 7.3 Application "Check Weighing"




The **"Check weighing"** application allows you to check the deviation of a sample weight within a tolerance limit to a reference target weight.

**Requirement:** The function "CHECK" must be assigned to the «F» key (see advanced menu topic "ASSIGN:F").



- Activate function "CHECK" by pressing and holding the «F» key.



**Step 1: Check Weighing first requires the setting of a reference weight that should corresponds to the nominal weight, there are 2 possibilities:**

**1A** Setting the reference **in manual mode** (enter nominal weight).

**1B** Setting the reference **in weighing mode** (weigh nominal weight).


**Step 2: Check weighing needs the upper and lower limits, there are 2 possibilities::**

**2A** Setting the **upper and lower limits in percentage**.

**2B** Setting the **upper and lower limits by weight**.

**Step 3: Setting tolerance beep**


**3** Activate or deactivate **tolerance beep**.



Setting possibility:

**1A** **Setting the reference in manual mode** (enter nominal weight)


- 1 Press «←» to activate manual mode.
- 2 Select the reference target weight by scrolling up («+» key) or down («-» key). Speed up by press and hold.
- 3 Press «←» to confirm the nominal weight.



Setting possibility:

**1B** **Setting the reference in weighing mode** (weigh nominal weight)

- 1 Press «→0/T←» to tare the balance and to activate the weighing mode. If needed: place empty container on the weighing pan and tare again.
- 2 Load the nominal weight.
- 3 Press «←» to confirm the nominal weight.




**Switching between manual mode and weighing mode**

- Press «↻» to switch between manual mode and weighing mode.

**Note:** By switching from weighing mode to manual mode the weight value will be transferred and can be changed manually.






Step 2, setting possibility:

**2A** Setting the upper and lower limits (in percentage):

- 1 Press «←» to start setting.
- 2 Press «←» to confirm the default limit of +/- 2.5 % or enter the limit value by scrolling up («+» key) or down («-» key). Press «←» to confirm the limits.


**Note:** Press «↶» to switch between "UNIT 1" and Unit "%".



Step 2, setting possibility:


**2B** Setting the upper and lower limits by weight:

- 1 Press «←» to start setting.
- 2 Press «↶» to switch to UNIT 1.
- 3 Press «←» to confirm the default limit or enter the limit value by scrolling up («+» key) or down («-» key). Press «←» to confirm the limits.



**Switching between percentage and weight unit 1**

- Press «↶» to switch between setting in percentage and setting by weight .



Step 3:

**3** Setting tolerance beep:

The tolerance beep indicates whether the weighing sample lies within the tolerance by beeping three times.


**Note:** The beep level corresponds to the setting in menu topic "STB.BEEP" (Basic menu). If "STB.BEEP" is set to "OFF", the tolerance beep level is medium.

- To activate tolerance beep press «←». To deactivate tolerance beep press «↶» to select "N" and press «←».

**Note:**

- If without any key press within 60 seconds, the balance returns to the previous active application. Press «C» to cancel and returns to the previous active application.
- The nominal weight must be at least 10 digit.

**On completion of the setting procedure, your balance is ready for checkweighing.**




### Weighing-in-Aid


The Weighing-in-Aid helps you quickly determine the position of the sample weight regarding the tolerance.

- 1** Lower limit
- 2** Target weight
- 3** Upper limit

## 7.4 Application "Statistics"




The "Statistics" application allows you to generate statistics of weighing values. 1 to 999 values are possible. **Requirement:** The function "STAT." must be assigned to the «F» key (see advanced menu topic "ASSIGN:F"). Connect a printer or a PC if present.



- 1 Activate function "STAT." by pressing and holding the «F» key.
- 2 To continue the last statistics press «←». For a new statistical evaluation press «↶» (or «+», «-») to select "CLR.M:YES" and press «←» to clear the memory.

**Note:** If the memory is already cleared (sample counter is 0) the memory clear question will be not displayed.



### Weighing the first sample weight:

- 1 Press «→O/T←» to zero/tare the balance if needed.
- 2 Load the first sample weight.
- 3 Press «←». The display shows the sample count "- 1 -" and the current weight is stored as sample and the weight is printed out. **Note:** When the sample counter is displayed you may press «C» to undo (drop) this sample.
- 4 Unload the first sample weight.


### Weighing further sample weights:

The same procedure as for the first sample weight.

- 1...999 samples are possible.
- The next value will be accepted if the sample weight is in the range 70% –130% of the current average value. "OUT OF RANGE" will be displayed if the sample is not accepted.

















### Results:

- If the numbers of sample are greater than or equal to 2, press «», the results are displayed and printed.

### Displayed results:

- 1 Press «←» to show the next statistical value.
- 2 Press «C» to cancel displaying results and to continue weighing next sample.

		0.5 seconds
number of samples	 →  5 ←	
average	 →  50.530 g ←	
standard deviation	 →  3.961 g ←	
relative standard deviation	 →  7.84 % ←	
lowest value (minimum)	 →  46.36 g ←	
highest value (maximum)	 →  55.81 g ←	
different between the minimum and the maximum	 →  9.45 g ←	

**Displayed results:**

- 1 Press «←» to show the next statistical value.
- 2 Press «C» to cancel displaying results and to continue weighing next sample.

sum of all values



**Printout:**


```
----- Statistics -----  
21.Jan 2010      12:56  
  
METTLER TOLEDO  
  
Balance Type      JP4002G  
SNR               1234567890  
-----  
1                46.36 g  
2                55.81 g  
3                47.49 g  
4                53.28 g  
5                49.71 g  
n                5  
x                50.530 g  
s dev           3.961 g  
s rel           7.84 g  
Min.            46.36 g  
Max.            55.81 g  
Diff            9.45 g  
Sum             252.65 g  
-----
```

## 7.5 Application "Totaling"




The "**TOTALING**" application allows you to weigh in different samples to add their weight values and to totalize them. 1 to 999 samples are possible.

**Requirement:** The function "TOTAL" must be assigned to the «F» key (see advanced menu topic "ASSIGN:F").



- 1 Activate function "TOTAL" by pressing and holding the «F» key.
- 2 For a new totaling evaluation press «CLR.M» (or «+» or «-») to enter "CLR.M: YES" and press «CLR» to clear the memory.  
**Note:** If the memory is already cleared (sample counter is 0) the memory clear question will be not displayed.
- 3 Press «→0/T←» to zero or tare the balance.



### Weighing in the sample weight:

- 1 If using a container: place empty container on the weighing pan and press «→0/T←» to zero or tare the balance.
- 2 Load the first sample weight.
- 3 Press «CLR». The display shows the sample count "- 1 -" and the current weight is stored.  
**Note:** When the sample counter is displayed you may press «C» to undo (drop) this sample.
- 4 Unload the first sample weight. The display shows zero.

### Weighing in further sample weights:

The same procedure as for the first sample weight.

- 1...999 samples are possible.




### Results:

- If the numbers of sample are greater than or equal to 2, press «PRINT», the results are displayed and printed.

### Displayed results:

- 1 Press «CLR» briefly to show the totalized value.
- 2 Press «C» briefly to cancel.



**Printout:**

```
----- Totaling -----  
21.Jan 2010      12:56  
  
METTLER TOLEDO  
  
Balance Type      JP2002G  
SNR                1234567890  
-----  
1                  46.36 g  
2                  55.81 g  
3                  47.49 g  
4                  53.28 g  
5                  49.71 g  
6                  53.93 g  
.                    
.                    
.                    
n                      879  
Total              8789.79 g  
-----
```

## 7.6 Application "Multiplication Factor Weighing"




The "Multiplication Factor Weighing" application allows you to multiply the weight value (in grams) by a predefined factor (result = factor \* weight) and have it calculated to a predefined number of decimal places.

**Requirement:** The function "FACTOR.M" must be assigned to the «F» key (see advanced menu topic "ASSIGN:F").




- Activate function "FACTOR.M" by pressing and holding the «F» key.



### 1 Setting the factor value:

- 1 Press «←» to execute "SET.F.MUL". Either the factor 1 appears as default value or the factor that was saved most recently.
- 2 Press «→» to select a digit. The selected digit is blinking.
- 3 For changing digits, press «+» to scroll up or «-» to scroll down.
- 4 Press «←» to confirm the selected factor (no automatic acceptance).

**Note:** Zero for multiplication factor value is outside the allowed range, the error message "FACTOR OUT OF RANGE" will be displayed.



### 2 Setting the step value:


"SET.STEP" appears in the display, and the program changes automatically to allow the display increments to be entered. The smallest possible display increment appears as default value, or the last value that was saved.

- 1 Press «←» to execute "SET.STEP".
- 2 Press «→» to select a digit. The selected digit is blinking.
- 3 For changing digits, press «+» to scroll up or «-» to scroll down.
- 4 Press «←» to confirm the selected step (no automatic acceptance).

**Note:** The allowed range for the step depends on the factor and the resolution of the balance. If it is outside the allowed range the error message "STEP OUT OF RANGE" will be displayed.

**Note:** If without any key press within 60 seconds, the balance returns to the previous active application. Press «C» to cancel and returns to the previous active application.

**On completion of the setting procedure, your balance is ready for multiplication factor weighing.**



### Weighing procedure

- 1 Press «→0/T←» to zero/tare.
- 2 Load sample weight on weighing pan.
- 3 Read the result. The appropriate calculation is then made using the weight of sample and the selected factor, the result being displayed with the selected display step.  
**Note:** No units are displayed.
- 4 Unload sample weight.

### toggling between displaying the calculated value and the measured weight:

You can use the «↶» key to toggle between the calculated Value, weight value "UNIT 1", "RECALL" value (if selected) and weight value "UNIT 2" (if different from "UNIT 1").



## 7.7 Application "Division Factor Weighing"




The "Division Factor Weighing" divide a predefined factor by the weight value (in grams) (result = factor / weight) and have it rounded to a predefined number of decimal places.

**Requirement:** The function "FACTOR.D" must be assigned to the «F» key (see advanced menu topic "ASSIGN:F").




- Activate function "FACTOR.D" by pressing and holding the «F» key.



### 1 Setting the Factor Value:

- 1 Press «←» to execute "SET.F.DIV". Either the factor 1 appears as default value or the factor that was saved most recently.
- 2 Press «→» to select a digit. The selected digit is blinking.
- 3 For changing digits, press «+» key to scroll up or «-» to scroll down.
- 4 Press «←» briefly to confirm the selected factor (no automatic acceptance).

**Note:** Zero for division factor value is outside the allowed range, the error message "FACTOR OUT OF RANGE" will be displayed.



### 2 Setting the step value:


"SET.STEP" appears in the display, and the program changes automatically to allow the display increments to be entered. The smallest possible display increment appears as default value, or the last value that was saved.

- 1 Press «←» to execute "SET.STEP".
- 2 Press «→» to select a digit. The selected digit is blinking.
- 3 For changing digits, press «+» to scroll up or «-» to scroll down.
- 4 Press «←» to confirm the selected step (no automatic acceptance).

**Note:** The allowed range for the step depends on the factor and the resolution of the balance. If it is outside the allowed range the error message "STEP OUT OF RANGE" will be displayed.

**Note:** If without any key press within 60 seconds, the balance returns to the previous active application. Press «C» to cancel and returns to the previous active application.

**On completion of the setting procedure, your balance is ready for division factor weighing.**



### Weighing procedure

- 1 Press «→0/T←» to zero/tare.
- 2 Load sample weight on weighing pan.
- 3 Read the result. The appropriate calculation is then made using the weight of sample and the selected factor, the result being displayed with the selected display step.  
**Note:**No units are displayed. To avoid a division by zero, the factor division is not calculated at zero.
- 4 Unload sample weight.

### Toggle between displaying the calculated value and the measured weight:

You can use the «G» key to toggle between the calculated Value, weight value "UNIT 1", "RECALL" value (if selected) and weight value "UNIT 2" (if different from "UNIT 1").

## 7.8 Application "Density"

**Note:** This Application is only available with JP models.



The "**Density**" application allows you to determine the density of solid bodies and liquids. Determination of the density uses **Archimedes' principle** according to which a body immersed in a fluid undergoes an apparent loss in weight which is equal to the weight of the fluid it displaces.

To determine the density of solid bodies, we recommended you to work with the optional density kit which contains all the attachments and aids needed for convenient and precise density determination. To determine the density of liquids, you additionally need a sinker which you can also obtain from your METTLER TOLEDO dealer.


### Note for performing of density determinations:

- You can also use the hanger for weighing below the balance which belongs to your balance.
- We recommended you to consult the operating instructions enclosed with the density kit.
- If a METTLER TOLEDO printer is attached to your balance, the settings will be automatically recorded.

**Requirement:** The function "DENSITY" must be assigned to the «F» key (see advanced menu topic "ASSIGN:F"). Density kit is installed.




- Activate function "DENSITY" by pressing and holding the appropriate assigned «F» key.



### Setting the method for density determination

- 1 Select: "SOLID", the function for the density determination of solids, or "LIQUID", the function for the density determination of liquids with a sinker.
- 2 Press «←» to confirm the selection




### Switching the display between user guidance and weighing

- Press «↻» to toggle the display between user guidance and weighing.


### 7.8.1 Density Determination of Solids

**Requirement:** The method "SOLID" is set.



### Setting the parameter of the auxiliary liquid


- 1 Select the auxiliary liquid by scrolling with «↻» (or «-» up / «+» down): "H-2-O" for distilled water, "ETHANOL" or "FREE" for a freely definable auxiliary liquid.
- 2 Press «←» to confirm the selection.



### If you have selected water or ethanol as the auxiliary liquid:

- 1 Enter the current temperature of the auxiliary liquid (read off on thermometer). Change the value by scrolling up «+» or down «-». The temperature ranges from 10 °C to 30.9 °C.
- 2 Press «←» to confirm the value.

**Note:** The densities of distilled water and ethanol in the range 10 °C to 30.9 °C are stored in the balance.



### If you have selected a freely definable auxiliary liquid:


Enter the density of the auxiliary liquid at the current temperature (read off on thermometer).

- 1 Press «←» to select a digit. The selected digit is blinking.
- 2 For changing digits, press «+» to scroll up or «-» to scroll down.
- 3 Press «←» to confirm the selected value.

**Note:** If without any key press within 60 seconds or by pressing «C», the balance returns to the previous active application.

**On completion of the settings, your balance is ready for performing the density determination of liquids.**

**Note:** Taring the balance is possible at any time.




The balance prompts you: "PRESS ENTER TO START".

- Press «←» to start. Tare/Zero is executed.




The balance prompts you to weigh the solid in air "WEIGH IN AIR".

- 1 Load the solid.
- 2 Press «←» to initiate the measurement.



The balance prompts you to weigh the solid in the auxiliary liquid "WEIGH IN LIQUID".

- 1 Load the solid.
- 2 Press «←» to initiate the measurement.



The balance now shows the determined density of the solid.

### Note:


- This result has already been corrected for the air buoyancy. The buoyancy caused by the two immersed wires ( $\varnothing$  0.6 mm) can be neglected.
- By pressing «C», the balance returns to "PRESS ENTER TO START".

### Result:

Press «», the result will be printed.




**Sample printout:**



**7.8.2 Density Determination of Liquids**

**Requirement:** The method "LIQUID" is set.



**Setting the displacement volume of your sinker**

Press «←» to confirm the default value of  $10.0\text{ cm}^3$  or change it if needed:

- 1 Press «↶» to select a digit. The selected digit is blinking.
- 2 For changing digits, press «+» to scroll up or «-» to scroll down
- 3 Press «←» to confirm the selected value.

**Note:** If without any key press within 60 seconds or by pressing «C», the balance returns to the previous active application.


**On completion of the settings, your balance is ready for performing the density determination of liquids.**

**Note:** Taring the balance is possible at any time.





The balance prompts you: "PRESS ENTER TO START".

- Press «←» to start.



The balance prompts you to weigh the sinker in air "WEIGH IN AIR".

- 1 Position the sinker.
- 2 Press «←» to initiate the measurement.



The balance prompts you to weigh the sinker in the liquid "WEIGH IN LIQUID".

- 1 Pour the liquid into the beaker. Make sure that the sinker is immersed by at least 1 cm in the liquid, and that there are no air bubbles in the container.
- 2 Press «←» to initiate the measurement.

The balance now shows the determined density of the liquid at the current temperature (read off on the thermometer).

**Note:**

- This result has already been corrected for the air buoyancy. The buoyancy caused by the immersed wire (Ø 0.2 mm) of the sinker can be neglected.
- By pressing «C», the balance returns to "PRESS ENTER TO START".

**Result:**

Press «☰», the result will be printed.

**Sample printout:**

```

---- Density Liquid ----
18.Mar 2010      20:14
Balance Type    JP703C
SNR             1234567890
-----
ID:             .....
Temp. of liquid: .....
Displaced liquid:
                10.0023 g
Density:        1.000 g/cm3
                =====
Signature
.....
-----

```

**7.8.3 Formulae Used to Calculate Density**

The "DENSITY" Application is based on the formulae listed below.

**Formulae for determining the density of solids with compensation for air density**

$$\rho = \frac{A}{A-B} (\rho_0 - \rho_L) + \rho_L$$

$$V = \alpha \frac{A - B}{\rho_0 - \rho_L}$$

$\rho$  = Density of the sample

A = Weight of the sample in air

- B = Weight of the sample in the auxiliary liquid  
V = Volume of the sample  
 $\rho_0$  = Density of the auxiliary liquid  
 $\rho_L$  = Density of Air (0.0012 g/cm<sup>3</sup>)  
 $\alpha$  = Weight correction factor (0.99985), to take the atmospheric buoyancy of the adjustment weight into account

**Formula for determining the density of liquids with compensation for air density**

$$\rho = \alpha \frac{P}{V} + \rho_L$$

- $\rho$  = Density of the liquid  
P = Weight of the displaced liquid  
V = Volume of the sinker  
 $\rho_L$  = Density of air (0.0012 g/cm<sup>3</sup>)  
 $\alpha$  = Weight correction factor (0.99985), to take the atmospheric buoyancy of the adjustment weight into account

**Density Table for Distilled Water**

T/°C	0.0	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9
10.	0.99973	0.99972	0.99971	0.99970	0.99969	0.99968	0.99967	0.99966	0.99965	0.99964
11.	0.99963	0.99962	0.99961	0.99960	0.99959	0.99958	0.99957	0.99956	0.99955	0.99954
12.	0.99953	0.99951	0.99950	0.99949	0.99948	0.99947	0.99946	0.99944	0.99943	0.99942
13.	0.99941	0.99939	0.99938	0.99937	0.99935	0.99934	0.99933	0.99931	0.99930	0.99929
14.	0.99927	0.99926	0.99924	0.99923	0.99922	0.99920	0.99919	0.99917	0.99916	0.99914
15.	0.99913	0.99911	0.99910	0.99908	0.99907	0.99905	0.99904	0.99902	0.99900	0.99899
16.	0.99897	0.99896	0.99894	0.99892	0.99891	0.99889	0.99887	0.99885	0.99884	0.99882
17.	0.99880	0.99879	0.99877	0.99875	0.99873	0.99871	0.99870	0.99868	0.99866	0.99864
18.	0.99862	0.99860	0.99859	0.99857	0.99855	0.99853	0.99851	0.99849	0.99847	0.99845
19.	0.99843	0.99841	0.99839	0.99837	0.99835	0.99833	0.99831	0.99829	0.99827	0.99825
20.	0.99823	0.99821	0.99819	0.99817	0.99815	0.99813	0.99811	0.99808	0.99806	0.99804
21.	0.99802	0.99800	0.99798	0.99795	0.99793	0.99791	0.99789	0.99786	0.99784	0.99782
22.	0.99780	0.99777	0.99775	0.99773	0.99771	0.99768	0.99766	0.99764	0.99761	0.99759
23.	0.99756	0.99754	0.99752	0.99749	0.99747	0.99744	0.99742	0.99740	0.99737	0.99735
24.	0.99732	0.99730	0.99727	0.99725	0.99722	0.99720	0.99717	0.99715	0.99712	0.99710
25.	0.99707	0.99704	0.99702	0.99699	0.99697	0.99694	0.99691	0.99689	0.99686	0.99684
26.	0.99681	0.99678	0.99676	0.99673	0.99670	0.99668	0.99665	0.99662	0.99659	0.99657
27.	0.99654	0.99651	0.99648	0.99646	0.99643	0.99640	0.99637	0.99634	0.99632	0.99629
28.	0.99626	0.99623	0.99620	0.99617	0.99614	0.99612	0.99609	0.99606	0.99603	0.99600
29.	0.99597	0.99594	0.99591	0.99588	0.99585	0.99582	0.99579	0.99576	0.99573	0.99570
30.	0.99567	0.99564	0.99561	0.99558	0.99555	0.99552	0.99549	0.99546	0.99543	0.99540

### Density Table for Ethanol

T/°C	0.0	0.1	0.2	0.3	0.4	0.5	0.6	0.7	0.8	0.9
10.	0.79784	0.79775	0.79767	0.79758	0.79750	0.79741	0.79733	0.79725	0.79716	0.79708
11.	0.79699	0.79691	0.79682	0.79674	0.79665	0.79657	0.79648	0.79640	0.79631	0.79623
12.	0.79614	0.79606	0.79598	0.79589	0.79581	0.79572	0.79564	0.79555	0.79547	0.79538
13.	0.79530	0.79521	0.79513	0.79504	0.79496	0.79487	0.79479	0.79470	0.79462	0.79453
14.	0.79445	0.79436	0.79428	0.79419	0.79411	0.79402	0.79394	0.79385	0.79377	0.79368
15.	0.79360	0.79352	0.79343	0.79335	0.79326	0.79318	0.79309	0.79301	0.79292	0.79284
16.	0.79275	0.79267	0.79258	0.79250	0.79241	0.79232	0.79224	0.79215	0.79207	0.79198
17.	0.79190	0.79181	0.79173	0.79164	0.79156	0.79147	0.79139	0.79130	0.79122	0.79113
18.	0.79105	0.79096	0.79088	0.79079	0.79071	0.79062	0.79054	0.79045	0.79037	0.79028
19.	0.79020	0.79011	0.79002	0.78994	0.78985	0.78977	0.78968	0.78960	0.78951	0.78943
20.	0.78934	0.78926	0.78917	0.78909	0.78900	0.78892	0.78883	0.78874	0.78866	0.78857
21.	0.78849	0.78840	0.78832	0.78823	0.78815	0.78806	0.78797	0.78789	0.78780	0.78772
22.	0.78763	0.78755	0.78746	0.78738	0.78729	0.78720	0.78712	0.78703	0.78695	0.78686
23.	0.78678	0.78669	0.78660	0.78652	0.78643	0.78635	0.78626	0.78618	0.78609	0.78600
24.	0.78592	0.78583	0.78575	0.78566	0.78558	0.78549	0.78540	0.78532	0.78523	0.78515
25.	0.78506	0.78497	0.78489	0.78480	0.78472	0.78463	0.78454	0.78446	0.78437	0.78429
26.	0.78420	0.78411	0.78403	0.78394	0.78386	0.78377	0.78368	0.78360	0.78351	0.78343
27.	0.78334	0.78325	0.78317	0.78308	0.78299	0.78291	0.78282	0.78274	0.78265	0.78256
28.	0.78248	0.78239	0.78230	0.78222	0.78213	0.78205	0.78196	0.78187	0.78179	0.78170
29.	0.78161	0.78153	0.78144	0.78136	0.78127	0.78118	0.78110	0.78101	0.78092	0.78084
30.	0.78075	0.78066	0.78058	0.78049	0.78040	0.78032	0.78023	0.78014	0.78006	0.77997

Density of C<sub>2</sub>H<sub>5</sub>OH according to the "American Institute of Physics Handbook".



## 7.9 Application "Routine Test"



The "**Routine Test**" application allows you to determine the sensitivity of the balance. More about periodic sensitivity tests (routine tests) see: **GWP**<sup>®</sup> (Good Weighing Practice) on [www.mt.com/gwp](http://www.mt.com/gwp).


GWP gives clear recommendation for routine testing:

- how should I test my balance?
- how often?
- where can I reduce efforts?

More about test weights see [www.mt.com/weights](http://www.mt.com/weights).

### Requirement:


- The function "R.TEST" must be assigned to «F» key (see advanced menu topic "ASSIGN:F").
- It is recommended to connect a printer or a PC to the balance for showing the results.



- 1 Activate function "R.TEST" by pressing and holding the assigned «F» key.
- 2 Select "TARE:NO" (no tare weight used).  
If a tare weight is used during the test select "TARE:YES" (use a tare weight). To toggle between "TARE:YES" and "TARE:NO" use «↔» (or «+» or «-»).
- 3 Press «←» to confirm the selection.

### Note:


- It is recommended to test the sensitivity without tare load. (factory setting "TARE:NO").
- If using tare: Make sure that tare weight plus test weight is not exceeding max. load.



### Setting the reference test weight value

The default value of the test weight: Next smaller OIML weight than the maximum load of your balance according to the GWP<sup>®</sup> recommendation.

- 1 For changing the value, press «+» to scroll up or «-» to scroll down. Progressing speed by press and hold.
- 2 Press «←» to confirm the value.




### Setting the Control Limit

The default value of the control limit:

Test weight x weighing process tolerance / 2

Example: 5000 g x 0.1% / 2 = 2.50 g.

- 1 For changing the value, press «+» to scroll up or «-» to scroll down. Progressing speed by press and hold.
- 2 Press «←» to confirm the value.




### Setting the Warning Limit

The default value of the warning limit:  
 Warning limit = control limit / safety factor  
 Example: 2.5 g / 2 = 1.25 g.

- 1 For changing the value, press «+» to scroll up or «-» to scroll down. Progressing speed by press and hold.
- 2 Press «←» to confirm the value.

**Note:** The default values of control limit and the warning limit are evaluated according the GWP recommendation. These are based under the assumption that the weighing process tolerance is 0.1% and the safety factor is 2.



### On completion of the setting procedure, your balance is ready for the routine test procedure.

**Note:** The test weight must be acclimatized to the ambient temperature of the balance.

- 1 Press «←» to start the test.
- 2 Follow the instructions on the display. If the test weight value is flashing: Load the test weight (displayed value).

The printout starts after the weighing pan is unloaded.

### Exit the current test procedure:

- Press and hold « $\Delta\Delta$ » for executing a new application.

### Printout:

```

----- Routine Test -----
21.Jan 2010      12:56

METTLER TOLEDO

Balance Type      JP6002G
SNR               1234567890

Sensitivity:
Test weight      5000.00 g
Value            5000.11 g
Warning L.       1.25 g
Control L.       2.50 g
Warning L.       OK
Control L.       OK

Signature
.....
-----
  
```

### What if Warning Limit or Control Limit are "FAILED"?

The "SOP for Periodic Sensitivity Tests (Routine Tests)" provides information about measures when routine tests fail. Find a download version of these SOPs on [www.mt.com/gwp](http://www.mt.com/gwp), link "GWP® The Program / Routine Operation".

### Content of SOP:

- Preparation
- Test procedure

- Evaluation
- Deviation
  - If Warning Limit "FAILED"
  - If Control Limit "FAILED"

## 7.10 Application "Diagnostics"



The "**Diagnostics**" application allows you to carry out predefined diagnostics tests and to view or print predefined sets of balance information. This diagnostics tool helps you find errors faster and more efficiently.

**Requirement:** A printer or a PC is connected to the balance for showing the results.

- 1 Activate "ADVANCE." menu. (See section menu operation)
- 2 Activate function "DIAGNOS." by pressing «←↓».
- 3 Use «↶» to select appropriate tests.

### 7.10.1 Repeatability Test

The repeatability test allows you to repeat tests with internal weight for a given number of times.

**Note:** On models with internal weights only.

- 1 Press «←↓» to activate repeatability test "REPEAT.T". "R.TST. 10" appears on the Display.
- 2 Enter the number of times (blinking) by pressing «+» or «-». Possible values are 5, 10 (default), 20, 50, 100 times.
- 3 Press «←↓» to start the test. The message "RUNNING REPEAT TEST" is displayed till the tests are completed.
- 4 Press «☰» to print the test information..
- 5 Press «←↓» to scroll forward through the displayed list.
- 6 Press «C» to cancel the test procedure. The balance will return to the topic "DIAGNOS.".

**Sample Information Displayed:**

Displayed for 0.5 s	Display
"S DEV"	* 0.004 g
"MAX.TEMP"	21.2 °C
"MIN.TEMP"	21.0 °C
"AVG.TEMP"	21.1 °C
"TOT.TIME"	00:01:26

## Sample Printout:

```
-- Repeatability Test --
21.Jan 2010      11:34

METTLER TOLEDO

Balance Type      JP4002G
SNR               1234567890
SW               V1.00
Temperature       21.3 °C
No. of tests      10
-----
1. Time           00:00:00
1. Temp           21.3 °C
2. Time           00:00:04
2. Temp           21.3 °C
.
.
.
-----
s Dev            0.004 g
Max Temp         21.3 °C
Min Temp         21.3 °C
Mean Temp        21.3 °C
Total Time       00:00:44
-----
```



### Examples:

Repeatability test is a tool to do functional check with the balance. It may be performed:

- **To check function of balance**
  - during installation to store print out with installation documents.
  - after preventative maintenance to store print out with installation maintenance report.
  - when remarkable decrease of weighing performance occurs, so that you can email/fax print out to service support provider for diagnose purposes.
- **To develop the optimal environment settings** (see menu topic "ENVIRON.").  
Measure the time you need to perform repeatability test with each "STABLE", "STD." and "UNSTAB." setting.  
The setting with the fastest total time suits best for the existing environmental conditions.

## 7.10.2 Display Test

The display test allows you to test the display of the balance.

- 1 Press «» to start "DISPLAY".  
All possible segments and icons on the display will illuminate.
- 2 Press «» to print the test information.
- 3 Press «**C**» to cancel the test procedure. The balance will return to the topic "DIAGNOS".

### Sample Printout:

```
----- Display Test -----
21.Jan 2010      11:34

METTLER TOLEDO




Balance Type      JP703C
SNR               1234567890
SW               V1.00
Display Test      DONE
-----
```

### 7.10.3 Key Test

The key test allows you to test the keys of the balance.

- 1 Press «←» to start "KEYPAD.T".
- 2 The message "KEY TEST - PRESS KEY TO BE TESTED" is displayed scrolling during the duration of the key test. Press every Key briefly. Each press of a key beeps and echoes with "OK" on the display.
- 3 Second press «C» key to print the test information. The test procedure will be cancelled and the balance will return to the topic "DIAGNOS.". If a key has not been tested before printing, then the test results will be indicated with a "----" line.

#### Sample Information Displayed:

Key	Display
«  »	1/10.D.OK
«  »	PRINT.OK
«←»	MINUS.OK
«+»	PLUS OK
«  »	TOGGL.OK
«←↓»	ENTER.OK
«C»	C OK
«→0/T←»	O/T OK

### Sample Printout:

```
----- Key Test -----
21.Jan 2010      11:34

METTLER TOLEDO

Balance Type      JP703C
SNR               1234567890
SW               V1.00
1/10 d Key       OK
Print Key        OK
Minus Key        OK
Plus Key         OK
Toggle Key       OK
Enter Key        OK
Zero/Tare Key    OK
Cancel Key       OK
-----
```

## 7.10.4 Motor Test

The motor test allows you to test the calibration motor of the balance.

**Note:** On models with internal weight only.

- 1 Press «←|» to start "CAL.MOT.T".  
"RUNNING" is displayed during the Motor Test. A motor test is deemed successful when all the motor positions have been successfully tested. At the end of the test, the test information will be printed.
- 2 Press «≡» for printout.
- 3 Press «C» to cancel the test procedure. The balance will return to the topic "DIAGNOS.".

### Sample Printout:

```
----- Motor Test -----  
21.Jan 2010      11:34  
  
METTLER TOLEDO  
  
Balance Type      JP703C  
SNR              1234567890  
SW               V1.00  
Motor Test       OK  
-----
```

## 7.10.5 Balance History

The balance history function allows you to view and print the history of the balance.

- 1 Press «←|» to start "BAL.HIST" .
- 2 Press «←|» to scroll forward through the displayed list of balance history information.
- 3 Press «≡» for printout.
- 4 Press «C» to cancel the test procedure. The balance will return to the topic "DIAGNOS.".

### Sample Information Displayed:

Information	Display
Operation Time (year:day:hour)	00:018:04
Total load kg (t)	115.7191 kg
Number of weighings	1255
Number of key pressed	4931
Number of motor movements	1012
Backlight time (year:day:hour)	00:018:04
Next service due date	01:01:10

### Sample Printout:

```

--- Statistical Info ---
21.Jan 2010      11:34


METTLER TOLEDO

Balance Type      JP4002G
SNR               1234567890
SW               V1.00
-----
Operating time   18d 23h
Total weight loaded
                115.7191 kg
Number of weighings
                1255
Number of key presses
                4931
Motor movements
                1012
Backlight operating time
                18d 4h
Next service due date
                01.01.2010
-----

```

### 7.10.6 Calibration History

The "Calibration History" function allows you to view and print information of the last 30 (thirty) balance adjustment. Adjustments made by a service technician and normal user are counted together.

- 1 Press «←» to start "CAL.HIST".
- 2 Press «» for printout.
- 3 Press «←» key to scroll forward through the displayed list of Adjustments history information.
- 4 Press «C» to cancel the test procedure. The balance will return to the topic "DIAGNOS.".

#### Sample Information Displayed:

Note	Display	
S = External adjusted service	05:03:S	01
	-3 PPM	
I = Internal adjusted	04:03:I	02
	2 PPM	
	.	.
	.	.
	.	.
I = Internal adjusted	03:03:I	28
	-1 PPM	
E = External adjusted user	02:03:E	29
	4 PPM	
I = Internal adjusted	02:03:I	30
	1 PPM	



**Sample Printout:**

```

----- Calibration -----
05.Mar 2010      11:34


METTLER TOLEDO

Balance Type      JP204C
SNR               1234567890
-----
01 05.Mar 2010   11:34
External ADJ SERVICE
                  23.5°C
Diff              -3ppm
-----
02 04.Mar 2010   09:00
Internal ADJ
                  22.4°C
Diff              2ppm
-----
.
.
.
28 03.Mar 2010   10:59
Internal ADJ
                  22.6°C
Diff              -1ppm
-----
29 02.Mar 2010   16:34
External ADJ USER
                  24.6°C
Diff              4ppm
-----
30 02.Mar 2010   18:36
Internal ADJ
                  22.4°C
Diff              1ppm
-----

```

**7.10.7 Balance Information**

The balance information function allows you to view and print information about your balance.

- 1 Press «←|» to start "BAL.INFO".
- 2 Press «» for printout.
- 3 Press «←|» to scroll forward through the displayed list of Balance information.
- 4 Press «C» to cancel the test procedure. The balance will return to the topic "DIAGNOS".

**Sample information displayed:**

Information	Display
Balance type	TYPE ML4002
Max. load	MAX 4200 g
Software platform	PLATFORM RAINBOW
Serial number	SNR 1234567890
Type definition number	TDNR 9.6.3.411
Software version	SOFTWARE V1.00
Cell ID	CELL ID 1172400044
Cell type	CELL TYPE MMAI4000G2
Tolerance revision number	TOLERANCE NO2

Information	Display
Language	ENGLISH

**Sample Printout:**

```

-- Balance Information -
05.Mar 2010          11:34


METTLER TOLEDO

Balance Type      JP4002G
SNR               1234567890
SW               V1.00
Max. Load       4200 g
Platform         Rainbow
TDNR            9.6.3.411
Cell ID          1172400044
Cell Type        MMAI4000G2
Tolerance Rev.no.  2
Language         English
-----

```

**7.10.8 Service Provider Information**

The service provider Information function allows you to print information about your service provider.

- 1 Press «←|» to start "SRV.PROV". The service provider information will be displayed.
- 2 Press «». The service provider information will be printed and the balance will return to the topic "DIAG-NOS.".

**Sample Printout:**

```

--- Service Provider ---
21.Jan 2009          11:34

METTLER TOLEDO
Im Langacher
CH-8606 Greifensee
Switzerland
(+41) 044 944 22 11
-----

```

## 8 Communication with Peripheral Devices

### 8.1 Function PC-Direct

The numerical value displayed at the balance can be transferred to the cursor position in Windows Applications (e.g. Excel, Word) as by typing with the keyboard.

**Note:** The units will not be transferred.

#### Requirements

- PC with Microsoft Windows® operating system (Version 98, 98SE, ME, NT4.0, 2000, XP) and serial interface RS232.
- Windows Application (e.g. Excel).
- Balance to PC connection with cable RS232 (e.g. No. 11101051 see chapter accessories).
- Balance Interface Setting (see Interface Menu):
  - Topic "RS232": set "PC-DIR." and select the most appropriate option for the desired weighing result.
  - Save changes.


#### Settings at the PC

##### Note:

- With all country-specific keyboards, in which the "Shift" key must be pressed for entering numbers, "Caps Lock" must be activated for transferring of correct data (e.g. with french keyboards).
- The following examples are based on Windows XP.




- 1 Click "start".
- 2 Click "ControlPanel".
- 3 Click "Accessibility Options" in the Control Panel.



#### Accessibility Option

- 1 Click "General" Tab.
- 2 Enter a check mark at "Use Serial Keys".
- 3 Click "Settings".



#### Settings for SerialKeys

- 1 Select the serial port to be used for connection with the balance.
- 2 Set the baud rate to 9600
- 3 Click "OK".



### Complete the settings

- 1 Click "Apply" when active (wait until active).
- 2 Click "OK" .

**Note:** If the "serial key" is enabled, applications that use the same port may not function correctly. Remove the check mark from the check box "Use Serial Keys" to disable serial key function.

### Checking Operation

- 1 Start Excel (or another application) at the PC.
- 2 Activate a cell in Excel.

According to your selected "PC-DIR." option, the displayed values will appear in the column one after the other one in the different rows.

## 9 Firmware (Software) Updates

METTLER TOLEDO is continuously improving its balance firmware (software) for the benefit of customers. So that the customer can benefit quickly and easily from further developments, METTLER TOLEDO makes the latest firmware versions available on the Internet. The firmware made available on the Internet has been developed and tested by Mettler-Toledo AG using processes that meet the guidelines of ISO 9001. Mettler-Toledo AG does not, however, accept liability for consequences that might arise from using the firmware.

### 9.1 Operating Principle

You will find all the relevant information and updates for your balance on the METTLER TOLEDO website at the following address:

**[www.mettler-toledo-support.com](http://www.mettler-toledo-support.com)**

A program known as the "**e-Loader II**" is loaded onto your computer together with the firmware update. You can use this program to download the firmware to the balance. The "e-Loader II" can also save the settings in your balance before the new firmware is downloaded to it. You can reload the saved settings into the balance manually or automatically after the software is downloaded.

If the selected update includes an application that is not described in these instructions (or that has been updated in the meantime) you can download the corresponding instructions in Adobe Acrobat® PDF format.

#### Requirements

The minimum requirements for obtaining applications from the Internet and downloading them into your balance are as follows:

- PC with Microsoft Windows® operating system (Version 98, 98SE, ME, NT4.0, 2000, XP or Vista).
- Internet connection and web browser (e.g. MS Internet Explorer).
- PC to balance connection cable (e.g. No. 11101051 see chapter accessories)

### 9.2 Update Procedure

#### Installing the "e-Loader II" software from the Internet onto the PC.

- 1 Connect to the Internet.
- 2 Go to the site "**[www.mettler-toledo-support.com](http://www.mettler-toledo-support.com)**".
- 3 Enter the information required for registration on the METTLER TOLEDO Balance Support Site.
- 4 Click the "Customer Support" link and log in.
- 5 Click your Balance.
- 6 Click the firmware version you need and install it.



#### Loading the new firmware into the balance.

- Start the "e-Loader II" and follow the instructions, which will take you step-by-step through the installation.

## 10 Error and Status Messages


### 10.1 Error Messages

Error messages in the display draw your attention to incorrect operation or that the balance could not execute a procedure properly.

Error Message	Cause	Rectification
NO STABILITY	No stability.	Ensure more stable ambient conditions. If not possible, check settings for environment.
WRONG ADJUSTMENT WEIGHT	Wrong adjustment weight on pan or none at all.	Place required adjustment weight in center of pan.
REFERENCE TOO SMALL	Reference for piece counting too small.	Increase reference weight.
EEPROM ERROR - PLEASE CONTACT CUSTOMER SERVICE	EEPROM (memory) error.	Please contact METTLER TOLEDO customer service.
WRONG CELL DATA - PLEASE CONTACT CUSTOMER SERVICE	Wrong cell data.	Please contact METTLER TOLEDO customer service.
NO STANDARD ADJUSTMENT - PLEASE CONTACT CUSTOMER SERVICE	No standard calibration.	Please contact METTLER TOLEDO customer service.
PROGRAM MEMORY DEFECT - PLEASE CONTACT CUSTOMER SERVICE	Program memory defect.	Please contact METTLER TOLEDO customer service.
TEMP SENSOR DEFECT - PLEASE CONTACT CUSTOMER SERVICE	Temperature sensor defect.	Please contact METTLER TOLEDO customer service.
WRONG LOAD CELL BRAND - PLEASE CONTACT CUSTOMER SERVICE	Wrong load cell brand.	Please contact METTLER TOLEDO customer service.
WRONG TYPE DATA SET - PLEASE CONTACT CUSTOMER SERVICE	Wrong type data set.	Please contact METTLER TOLEDO customer service.
BATTERY BACKUP LOST - CHECK DATE TIME SETTINGS	Backup battery is empty. This battery ensures that the date and time are not lost when the balance is disconnected from power.	Connect the balance to the power supply for charging the battery (e.g. during the night) or contact METTLER TOLEDO customer service.
	Overload - The weight on the pan exceeds the weighing capacity of the balance.	Reduce the weight on the weighing pan.
	Underload	Check that the weighing pan is positioned correctly.
INITIAL ZERO RANGE EXCEEDED	Wrong weighing pan or pan is not empty.	Mount correct weighing pan or unload weighing pan.
BELOW INITIAL ZERO RANGE	Wrong weighing pan or pan is missing.	Mount correct weighing pan.
MEM.FULL	Memory full.	Clear the memory and start a new evaluation.
FACTOR OUT OF RANGE	Factor is outside the allow range.	Select a new factor.
STEP OUT OF RANGE	Step is outside the allow range.	Select a new step.
OUT OF RANGE	Sample weight is outside the allow range.	Unload the pan and load a new sample weight.

### 10.2 Status Messages

Status messages are displayed by means of small icons. The status icons indicate the following:

Status Icon	Signification
	<b>Service Reminder</b> Your balance is due for servicing. Contact your dealer's customer service department as soon as possible to have a technician service your balance. (See menu topic "SRV.ICON")

## 11 Cleaning and Service

Every now and then, clean the weighing pan, draft shield element, bottom plate, draft shield (depending on the model) and housing of your balance. Your balance is made from high-quality, durable materials and can therefore be cleaned using a damp cloth or with a standard, mild cleaning agent.


### Please observe the following notes:



- The balance must be disconnected from the power supply
- Ensure that no liquid comes into contact with the balance or the AC adapter.
- Never open the balance or AC adapter – they contain no components, which can be cleaned, repaired or replaced by the user.



- On no account use cleaning agents which contain solvents or abrasive ingredients, as this can result in damage to the operation panel overlay.
- Do not use wet, but only damp cloth for cleaning.



Please contact your METTLER TOLEDO dealer for details of the available service options. Regular servicing by an authorized service engineer ensures constant accuracy for years to come and prolongs the service life of your balance.



## 12 Interface Specification

### 12.1 RS232C Interface

Each balance is equipped with an RS232C Interface COM1 as standard for the attachment of a peripheral device (e.g. printer or computer).

Schematic	Item	Specification
	Interface type	Voltage interface according to EIA RS-232C/DIN66020 CCITT V24/V.28)
	Max. cable length	15 m
	Signal level	Outputs: +5 V ... +15 V (RL = 3–7 kΩ) –5 V ... –15 V (RL = 3–7 kΩ) Inputs: +3 V ... +25 V –3 V ... –25 V
	Connector	Sub-D, 9-pole, female
	Operating mode	Full duplex
	Transmission mode	Bit-serial, asynchronous
	Transmission code	ASCII
	Baud rates	600, 1200, 2400, 4800, 9600, 19200, 38400 (software selectable)
	Bits/parity	7-bit/none, 7-bit/even, 7-bit/odd, 8-bit/none (software selectable)
	Stop bits	1 stop bit
	Handshake	None, XON/XOFF, RTS/CTS (software selectable)
	End-of-line	<CR><LF>, <CR>, <LF> (software selectable)
	Power supply for 2nd display	+ 12 V, max 40 mA (software selectable, 2nd display mode only)

**Note:** The second interface COM2 if present, has no power supply on Pin 9 for a 2nd display.

### 12.2 MT-SICS Interface Commands and Functions

Many of the balances and scales used have to be capable of integration in a complex computer or data acquisition system.

To enable you to integrate balances in your system in a simple manner and utilize their capabilities to the full, most balance functions are also available as appropriate commands via the data interface.

All new METTLER TOLEDO balances launched on the market support the standardized command set "METTLER TOLEDO Standard Interface Command Set" (MT-SICS). The commands available depending on the functionality of the balance.

#### Basic information on data interchange with the balance

The balance receives commands from the system and acknowledges the command with an appropriate response.

#### Command formats

Commands sent to the balance comprise one or more characters of the ASCII character set. Here, the following must be noted:

- Enter commands only in uppercase.
- The possible parameters of the command must be separated from one another and from the command name by a space (ASCII 32 dec., in this description represented as  $\square$ ).

- The possible input for "text" is a sequence of characters of the 8-bit ASCII character set from 32 dec to 255 dec.
- Each command must be closed by C<sub>R</sub>L<sub>F</sub> (ASCII 13 dec., 10 dec.). The characters C<sub>R</sub>L<sub>F</sub>, which can be inputted using the Enter or Return key of most entry keypads, are not listed in this description, but it is essential they be included for communication with the balance.

### Example

#### S – Send stable weight value

Command	<b>S</b>	Get the current stable net weight value.
Response	<b>S</b> <u>S</u> <b>WeightValue</b> <u>Unit</u>	Current stable weight value in unit actually set under unit 1.
	<b>S</b> <u>I</u>	Command not executable (balance is currently executing another command, e.g. taring, or timeout as stability was not reached).
	<b>S</b> <u>+</u>	Balance in overload range.
	<b>S</b> <u>-</u>	Balance in underload range.

### Example

Command	<b>S</b>	Query a stable weight value.
Response	<b>S</b> <u>S</u> <u>U</u> <u>U</u> <u>U</u> <u>U</u> <u>U</u> <u>100.00</u> <u>g</u>	The current stable weight value is 100.00 g.

The available MT-SICS commands are listed in the table (depending on the model). For further information please refer to the Reference Manual "MT-SICS 11780711" downloadable from the Internet under [www.mt.com/sics-newclassic](http://www.mt.com/sics-newclassic).



	Description		Description
<b>@</b>	Cancel (Reset)	<b>M46</b>	Print interval
<b>C0</b>	Query/Set adjustment settings	<b>PW</b>	Piece counting: Query/Set piece weight
<b>C1</b>	Start adjustment according to current settings	<b>PWR</b>	Power on/off (PWR 0 means switch off completely, if balance is powered by battery)
<b>C2</b>	Start adjustment with external weight	<b>S</b>	Send stable weight value
<b>C3</b>	Start adjustment with internal weight	<b>SI</b>	Send weight value immediately
<b>D</b>	Display text sent to balance	<b>SIR</b>	Send weight value immediately and repeat
<b>DAT</b>	Date query/set	<b>SIRU</b>	Send weight value with currently displayed unit immediately and repeat
<b>DW</b>	Display weight	<b>SIU</b>	Send weight value with currently displayed unit immediately
<b>I0</b>	Commands implemented	<b>SM0</b>	Dynamic weighing: cancel all SMx commands
<b>I1</b>	MT-SICS level and MT-SICS versions	<b>SM1</b>	Dynamic weighing: Start immediately and send the result
<b>I2</b>	Balance data	<b>SM2</b>	Dynamic weighing: start after a minimum load is exceeded and send result
<b>I3</b>	Software version, type definition number	<b>SM3</b>	Dynamic weighing: start after a minimum load is exceeded, send result and repeat
<b>I4</b>	Query serial number (SNR)	<b>SM4</b>	Dynamic weighing: query/set time interval
<b>I5</b>	Query SW-identification number	<b>SNR</b>	Send stable weight value and repeat on weight change
<b>I10</b>	Query/set balance ID	<b>SNRU</b>	Send stable weight value with currently displayed unit and repeat on weight change
<b>I11</b>	Query balance type	<b>SR</b>	Send weight value on weight change
<b>I14</b>	Query balance information	<b>SRU</b>	Send stable weight value with currently displayed unit on weight change

	Description		Description
<b>K</b>	Keys: set configuration	<b>ST</b>	Send stable weight value on pressing (print) key
<b>M02</b>	Query/set environment	<b>SU</b>	Send stable weight value with currently displayed unit
<b>M03</b>	Query/set AutoZero	<b>T</b>	Tare
<b>M08</b>	Display brightness	<b>TA</b>	Get/Set tare weight value
<b>M09</b>	Display contrast	<b>TAC</b>	Clear tare value
<b>M11</b>	Beeper: Query/set volume	<b>TI</b>	Tare immediately
<b>M14</b>	List available language	<b>TIM</b>	Query/set time
<b>M15</b>	Query/set language	<b>TST0</b>	Query/set test function settings
<b>M17</b>	FACT: query/set single time criteria (no possibility to set "weekday")	<b>TST1</b>	Start test function according to current settings
<b>M22</b>	Custom unit definition Remarks: no possibility to set "name" of unit	<b>TST2</b>	Start test function with external weight
<b>M25</b>	Get application list	<b>TST3</b>	Start test function with internal weight
<b>M26</b>	Get/set current application	<b>UPD</b>	Query/set update rate of the host interface
<b>M27</b>	Adjustment history	<b>Z</b>	Zero
<b>M30</b>	+/- settings with nominal and tolerance	<b>ZI</b>	Zero immediately

## 13 Technical Data

### 13.1 General Data

#### Power Supply

- AC operation: AC/DC Adapter  
Primary: 100V–240V, 50/60Hz, 0.3 A  
Secondary: 12VDC, 0.84A (with electronic overload protection)  
Power supply to the balance: 8–20VDC, 10W  
 Use only with a tested AC Adapter with SELV output current.  
Ensure correct polarity 
- Battery operation: 8 standard AA (LR6) batteries (alkaline) for 8–15 hours of use.

#### Protection and Standards

- Overvoltage category: Class III
- Degree of pollution: 2
- Degree of Protection: Protected against dust and water: IP54 in use with weighing pan.
- Standards for safety and EMC: See Declaration of Conformity
- Range of application: For use only in dry interior rooms

#### Environmental conditions

- Height above mean sea level: up to 4000 m
- Ambient temperature range: 10 to 30 °C
- Relative air humidity: 10% to 80 % at 31 °C, linearly decreasing to 50 % at 40 °C, non-condensing

#### Materials

- Housing: Top Housing: Plastic (ABS)  
Bottom housing: Die-cast aluminum, lacquered
- Weighing pan: Stainless steel X2CrNiMo 17-12-2 (1.4404)
- Draft shield element: with 0.1 mg models: Stainless steel X2CrNiMo 17-12-2 (1.4404)
- Draft shield: Plastic (ABS), glass
- In-use-cover: Plastic (ABS)

### 13.2 Model-Specific Data

#### 13.2.1 Carat Balances with Readability of 0.001 ct

##### Technical Data

Model	JP703C	JS703C	JP1203C
Maximum load	700 ct / 140 g	700 ct / 140 g	1200 ct / 240 g
Readability	0.001 ct / 0.0001 g	0.001 ct / 0.0001 g	0.001 ct / 0.0001 g
Taring range	0...700 ct	0...700 ct	0...1200 ct
Repeatability (sd)	0.001 ct / 0.0001 g	0.001 ct / 0.0001 g	0.001 ct / 0.0001 g
Linearity	0.001 ct / 0.0002 g	0.001 ct / 0.0002 g	0.001 ct / 0.0003 g
Sensitivity temperature drift (10...30°C)	1.5 ppm/°C	1.5 ppm/°C	1.5 ppm/°C
Internal adjustment	yes, FACT	yes	yes, FACT
Adjustment range with external weights	50...140 g	50...140 g	100...240 g
Weights for routine testing			
Large Weight/Class OIML/ASTM	100 g / F2/4	100 g / F2/4	200 g / F2/4
Small Weight/Class OIML/ASTM	5 g / E2/2	5 g / F1/3	10 g / F1/3
Minimum weight (acc. to USP)	0.3 g	0.3 g	0.3 g
Minimum weight (U=1%, k=2)	0.02 g	0.02 g	0.02 g

Model	JP703C	JS703C	JP1203C
Minimum weight (OIML)	0.01 g	0.01 g	0.01 g
Settling time, typ.	2 s	2 s	3 s
Weighing technology	MonoBloc	MonoBloc	MonoBloc
Interface RS232C	2 (COM1, COM2)	1 (COM1)	2 (COM1, COM2)
Usable height of draft shield [mm]	165	165	235
Weighing pan dimensions (WxD) [mm]	Ø 90	Ø 90	Ø 90
Balance dimensions (WxDxH) [mm]	193x290x266	193x290x266	193x290x331
Net Weight [kg]	3.6	3.4	4.1

#### Technical Data

Model	JS1203C	JP1603C	JS1603C
Maximum load	1200 ct / 240 g	1600 ct / 320 g	1600 ct / 320 g
Readability	0.001 ct / 0.0001 g	0.001 ct / 0.0001 g	0.001 ct / 0.0001 g
Taring range	0...1200 ct	0...1600 ct	1600 ct
Repeatability (sd)	0.001 ct / 0.0001 g	0.001 ct / 0.0001 g	0.001 ct / 0.0001 g
Linearity	0.001 ct / 0.0003 g	0.002 ct / 0.0003 g	0.002 ct / 0.0003 g
Sensitivity temperature drift (10...30°C)	1.5 ppm/°C	1.5 ppm/°C	1.5 ppm/°C
Internal adjustment	yes	yes, FACT	yes
Adjustment range with external weights	100...240 g	100...320 g	100...320 g
Weights for routine testing			
Large Weight/Class OIML/ASTM	200 g / F2/4	200 g / F2/4	200 g / F2/4
Small Weight/Class OIML/ASTM	10 g / E2/2	10 g / F1/3	10 g / F1/3
Minimum weight (acc. to USP)	0.3 g	0.3 g	0.3 g
Minimum weight (U=1%, k=2)	0.02 g	0.02 g	0.02 g
Minimum weight (OIML)	0.01 g	0.01 g	0.01 g
Settling time, typ.	2 s	2 s	2 s
Weighing technology	MonoBloc	MonoBloc	MonoBloc
Interface RS232C	1 (COM1)	2 (COM1, COM2)	1 (COM1)
Usable height of draft shield [mm]	235	235	235
Weighing pan dimensions (WxD) [mm]	Ø 90	Ø 90	Ø 90
Balance dimensions (WxDxH) [mm]	193x290x331	193x290x331	193x290x331
Net Weight [kg]	3.9	4.1	3.9

### 13.2.2 Gold Balances with Readability of 0.001 g

#### Technical Data

Model	JP303G	JS303G
Maximum load	320 g	320 g
Readability	0.001 g	0.001 g
Taring range	0...320 g	0...320 g
Repeatability (sd)	0.001 g	0.001 g
Linearity	0.002 g	0.002 g
Sensitivity temperature drift (10...30°C)	3 ppm/°C	3 ppm/°C
Internal adjustment (external weight)	yes, FACT	yes
Adjustment range with external weights	100...320 g	100...320 g
Weights for routine testing		
Large Weight/Class OIML/ASTM	200 g / F2/4	200 g / F2/4
Small Weight/Class OIML/ASTM	20 g / F1/3	20 g / F1/3
Minimum weight (acc. to USP)	3 g	3 g
Minimum weight (U=1%, k=2)	0.2 g	0.2 g
Minimum weight (OIML)	0.02 g	0.02 g
Settling time, typ.	1.5 s	1.5 s

Model	JP303G	JS303G
Weighing technology	MonoBloc	MonoBloc
Interface RS232C	2 (COM1, COM2)	1 (COM1)
Usable height of draft shield [mm]	165	165
Weighing pan dimensions (WxD) [mm]	Ø 120	Ø 120
Balance dimensions (WxDxH) [mm]	193x290x266	193x290x331
Net Weight [kg]	4.2	4.2

#### Technical Data

Model	JP503G	JS503G
Maximum load	520 g	520 g
Readability	0.001 g	0.001 g
Taring range	0...520 g	0...520 g
Repeatability (sd)	0.001 g	0.001 g
Linearity	0.002 g	0.002 g
Sensitivity temperature drift (10...30°C)	3 ppm/°C	3 ppm/°C
Internal adjustment (external weight)	yes, FACT	yes
Adjustment range with external weights	200...520 g	200...520 g
Weights for routine testing		
Large Weight/Class OIML/ASTM	500 g / F2/4	500 g / F2/4
Small Weight/Class OIML/ASTM	20 g / F1/3	20 g / F1/3
Minimum weight (acc. to USP)	3 g	3 g
Minimum weight (U=1%, k=2)	0.2 g	0.2 g
Minimum weight (OIML)	0.02 g	0.02 g
Settling time, typ.	1.5 s	1.5 s
Weighing technology	MonoBloc	MonoBloc
Usable height of draft shield [mm]	165	165
Weighing pan dimensions (WxD) [mm]	Ø 120	Ø 120
Balance dimensions (WxDxH) [mm]	193x290x266	193x290x331
Net Weight [kg]	4.2	4.2

### 13.2.3 Gold Balances with Readability of 0.01 g

#### Technical Data

Model	JP802G	JS802G
Maximum load	820 g	820 g
Readability	0.01 g	0.01 g
Taring range	0...820 g	0...820 g
Repeatability (sd)	0.01 g	0.01 g
Linearity	0.02 g	0.02 g
Sensitivity temperature drift (10...30°C)	3 ppm/°C	3 ppm/°C
Internal adjustment	yes, FACT	yes
Adjustment range with external weights	100...820 g	100...820 g
Weights for routine testing		
Large Weight/Class OIML/ASTM	500 g / F2/4	500 g / F2/4
Small Weight/Class OIML/ASTM	20 g / F2/4	20 g / F2/4
Minimum weight (acc. to USP)	30 g	30 g
Minimum weight (U=1%, k=2)	2 g	2 g
Minimum weight (OIML)	0.5 g	0.5 g
Settling time, typ.	1.5 s	1.5 s
Weighing technology	MonoBloc	MonoBloc
Interface RS232C	2 (COM1, COM2)	1 (COM1)
Weighing pan dimensions (WxD) [mm]	170x190	170x190

Model	JP802G	JS802G
Balance dimensions (WxDxH) [mm]	184x290x84	184x290x84
Net Weight [kg]	3.6	3.4

#### Technical Data

Model	JP2002G	JS2002G
Maximum load	2200 g	2200 g
Readability	0.01 g	0.01 g
Taring range	0...2200 g	0...2200 g
Repeatability (sd)	0.01 g	0.01 g
Linearity	0.02 g	0.02 g
Sensitivity temperature drift (10...30°C)	3 ppm/°C	3 ppm/°C
Internal adjustment	yes, FACT	yes
Adjustment range with external weights	1000...2200 g	1000...2200 g
Weights for routine testing		
Large Weight/Class OIML/ASTM	2000 g / F2/4	2000 g / F2/4
Small Weight/Class OIML/ASTM	100 g / F2/4	100 g / F2/4
Minimum weight (acc. to USP)	30 g	30 g
Minimum weight (U=1%, k=2)	2 g	2 g
Minimum weight (OIML)	0.5 g	0.5 g
Settling time, typ.	1.5 s	1.5 s
Weighing technology	MonoBloc	MonoBloc
Weighing pan dimensions (WxD) [mm]	170x190	170x190
Balance dimensions (WxDxH) [mm]	184x290x84	184x290x84
Net Weight [kg]	3.6	3.4

#### Technical Data

Model	JP3002G	JS3002G
Maximum load	3200 g	3200 g
Readability	0.01 g	0.01 g
Taring range	0...3200 g	0...3200 g
Repeatability (sd)	0.01 g	0.01 g
Linearity	0.02 g	0.02 g
Sensitivity temperature drift (10...30°C)	3 ppm/°C	3 ppm/°C
Internal adjustment	yes, FACT	yes
Adjustment range with external weights	1000...3200 g	1000...3200 g
Weights for routine testing		
Large Weight/Class OIML/ASTM	2000 g / F2/4	2000 g / F2/4
Small Weight/Class OIML/ASTM	100 g / F2/4	100 g / F2/4
Minimum weight (acc. to USP)	30 g	30 g
Minimum weight (U=1%, k=2)	2 g	2 g
Minimum weight (OIML)	0.5 g	0.5 g
Settling time, typ.	1.5 s	1.5 s
Weighing technology	MonoBloc	MonoBloc
Weighing pan dimensions (WxD) [mm]	170x190	170x190
Balance dimensions (WxDxH) [mm]	184x290x84	184x290x84
Net Weight [kg]	3.6	3.4

#### Technical Data

Model	JP4002G	JS4002G
Maximum load	4200 g	4200 g
Readability	0.01 g	0.01 g
Taring range	0...4200 g	0...4200 g

Model	JP4002G	JS4002G
Repeatability (sd)	0.01 g	0.01 g
Linearity	0.02 g	0.02 g
Sensitivity temperature drift (10...30°C)	3 ppm/°C	3 ppm/°C
Internal adjustment	yes, FACT	yes
Adjustment range with external weights	2000...4200 g	2000...4200 g
Weights for routine testing		
Large Weight/Class OIML/ASTM	2000 g / F2/4	2000 g / F2/4
Small Weight/Class OIML/ASTM	200 g / F2/4	200 g / F2/4
Minimum weight (acc. to USP)	30 g	30 g
Minimum weight (U=1%, k=2)	2 g	2 g
Minimum weight (OIML)	0.5 g	0.5 g
Settling time, typ.	1.2 s	1.2 s
Weighing technology	MonoBloc	MonoBloc
Weighing pan dimensions (WxD) [mm]	170x190	170x190
Balance dimensions (WxDxH) [mm]	184x290x84	184x290x84
Net Weight [kg]	3.6	3.4

#### Technical Data

Model	JP6002G	JP6002G
Maximum load	6200 g	6200 g
Readability	0.01 g	0.01 g
Taring range	0...6200 g	0...6200 g
Repeatability (sd)	0.01 g	0.01 g
Linearity	0.02 g	0.02 g
Sensitivity temperature drift (10...30°C)	3 ppm/°C	3 ppm/°C
Internal adjustment	yes, FACT	yes
Adjustment range with external weights	2000...6200 g	2000...6200 g
Weights for routine testing		
Large Weight/Class OIML/ASTM	5000 g / F2/4	5000 g / F2/4
Small Weight/Class OIML/ASTM	200 g / F2/4	200 g / F2/4
Minimum weight (acc. to USP)	30 g	30 g
Minimum weight (U=1%, k=2)	2 g	2 g
Minimum weight (OIML)	0.5 g	0.5 g
Settling time, typ.	1.2 s	1.2 s
Weighing technology	MonoBloc	MonoBloc
Weighing pan dimensions (WxD) [mm]	170x190	170x190
Balance dimensions (WxDxH) [mm]	184x290x84	184x290x84
Net Weight [kg]	3.3	3.1

### 13.2.4 Gold Balances with Readability of 0.1 g

#### Technical Data

Model	JP8001G	JS8001G
Maximum load	8200 g	8200 g
Readability	0.1 g	0.1 g
Taring range	0...8200 g	0...8200 g
Repeatability (sd)	0.1 g	0.1 g
Linearity	0.2 g	0.2 g
Sensitivity temperature drift (10...30°C)	5 ppm/°C	5 ppm/°C
Internal adjustment	yes, FACT	yes
Adjustment range with external weights	2000...8200 g	2000...6200 g




<b>Model</b>	<b>JP8001G</b>	<b>JS8001G</b>
Weights for routine testing		
Large Weight/Class OIML/ASTM	5000 g / F2/4	5000 g / F2/4
Small Weight/Class OIML/ASTM	200 g / F2/4	200 g / F2/4
Minimum weight (acc. to USP)	300 g	300 g
Minimum weight (U=1%, k=2)	20 g	20 g
Minimum weight (OIML)	5 g	5 g
Settling time, typ.	1 s	1 s
Weighing technology	MonoBloc	MonoBloc
Interface RS232C	2 (COM1, COM2)	1 (COM1)
Weighing pan dimensions (WxD) [mm]	170x190	170x190
Balance dimensions (WxDxH) [mm]	184x290x84	184x290x84
Net Weight [kg]	3.3	3.1

## 13.3 Dimensions

### 13.3.1 Carat Balances with Readability of 0.001 ct

**Models:**

JP703C  
JS703C  
JP1203C  
JS1203C  
JP1603C  
JS1603C



### 13.3.2 Gold Balances with Readability of 0.001 g


**Models:**

JP303G

JS303G

JP503G


JS503G



### 13.3.3 Gold Balances with Readability of 0.01 g


**Models:**

- JP802G
- JS802G
- JP2002G
- JS2002G
- JP3002G
- JS3002G
- JP4002G
- JS4002G
- JP6002G
- JS6002G










### 13.3.4 Gold Balances with Readability of 0.1 g


**Models:**  
JP8001G  
JS8001G



## 14 Accessories and Spare Parts

### 14.1 Accessories


	Description	Part No.
<b>Carat Pans</b>		
	Carat pan XS, Ø 50 mm / heigh 20 mm (set of 10 units)	12102565
	Carat pan S, Ø 80 mm / heigh 20 mm (set of 10 units)	12102645
	Carat pan M, Ø 90 mm / heigh 30 mm (set of 10 units)	12102646
	Carat pan L, Ø 90 mm / heigh 45 mm (set of 10 units)	12102647
<b>Density Determination</b>		
	Density kit ML-DNY-43 for NewClassic ML Balances (d = 0.1 mg/1 mg)	11142144
	Glass beaker, height 100 mm, Ø 60 mm	00238167
	Sinker for density of liquids in conjunction with Density Kit Calibrated (sinkers + certificate) Recalibrated (new certificate)	00210260 00210672 00210674



Calibrated thermometer with certificate

11132685


### Draft Shields



Draft shield ML-DS-21 for models with readability of 0.1 g up to 0.01 g.

12121015


### Printers



RS-P28/11 printer with RS232C connection to balance (with date, time and applications)


11124309

### Cables for RS232C Interface




RS9 – RS9 (m/f): connection cable for PC, length = 1 m

11101051




RS9 – RS25 (m/f): connection cable for PC, length = 1 m

11101052



RS9 – RS9 (m/m): connection cable for devices with DB9 (f) socket, length = 1 m


21250066



RS232 - USB converter – intelligent expansion module for connection to PC

11103691


### Auxiliary Displays



RS232 auxiliary display AD-RS-J7


12122380

### Power Supplies



AC/DC universal adapter (EU, USA, AU, UK) 100–240 VAC, 50/60HZ, 0.3 A, 12 VDC 0.84 A


11120270



PowerPac-M-12V, for mains independent operation of balances, 12 VDC/1 A


12122363

### Protective Covers



Protective cover for models with draft shield "165/235 mm"


12122030



Protective cover for models with square weighing pan

12122031


### Anti-theft Devices



Steel cable

11600361

### Software



LabX direct balance (simple data transfer)

11120340

### Adjustment Weights




OIML / ASTM Weights (with calibration certificate) see [www.mt.com/weights](http://www.mt.com/weights)




## 14.2 Spare Parts

### Carat Balances with Readability of 0.001 ct

Drawing	Pos	Description	Part No.
	1	Weighing pan Ø 90 mm	12122010
	2	Pan support	12122042
	3	Draft shield element	12122043
	4	Bottom plate	12122044
	5	Side glass door low	12122089
	6	Top glass door	12122033
	7	Pair of handles	12122035
	8	Leveling foot	12122040
	9	Battery-chamber cover	12122041
	10	Weighing below balance cap	12122029

### Gold Balances with Readability of 0.001 g

Drawing	Pos	Description	Part No.
	1	Weighing pan Ø 90 mm	12122010
		Weighing pan Ø 120 mm	12122037
	2	Pan support Ø 120 mm	12122045
	3	Bottom plate	12122044
	4	Side glass door low	12122089
	5	Top glass door	12122033
	6	Pair of handles	12122035
	7	Leveling foot	12122040
	8	Battery-chamber cover	12122041
9	Weighing below balance cap	12122029	

### Balances with readability of 10 mg with square weighing pan and draft shield element

Drawing	Pos	Description	Part No.
	1	Weighing pan 170 mm x 190 mm	12122048
	2	Pan support	12122049
	3	Draft shield element	12122050
	4	Pan support cap	11131029
	5	Leveling foot	12122040
	6	Battery-chamber cover	12122041
	7	Weighing below balance cap	12122029

### Balances with readability of 0.1 g with square weighing pan

Drawing	Pos	Description	Part No.
	1	Weighing pan 170 mm x 190 mm	12122048
	2	Pan support	12122049
	3	Pan support cap	11131029
	4	Leveling foot	12122040
	5	Battery-chamber cover	12122041
	6	Weighing below balance cap	12122029

## 15 Appendix

### 15.1 Conversion Table for Weight Units

Kilogram	1 kg	=	1000.0	g	1 g	=	0.001	kg
Milligram	1 mg	=	0.001	g	1 g	=	1000.0	mg
Microgram	1 µg	=	0.000001	g	1 g	=	1000000.0	µg
Carat	1 ct	=	0.2	g	1 g	=	5.0	ct
Pound	1 lb	=	453.59237	g	1 g	≈	0.00220462262184878	lb
Ounce (avdp)	1 oz	=	28.349523125	g	1 g	≈	0.0352739619495804	oz
Ounce (troy)	1 ozt	=	31.1034768	g	1 g	≈	0.0321507465686280	ozt
Grain	1 GN	=	0.06479891	g	1 g	≈	15.4323583529414	GN
Pennyweight	1 dwt	=	1.55517384	g	1 g	≈	0.643014931372560	dwt
Momme	1 mom	=	3.75	g	1 g	≈	0.266666666666667	mom
Mesghal	1 msg	≈	4.6083	g	1 g	≈	0.217	msg
Tael Hong Kong	1 tlh	=	37.429	g	1 g	≈	0.0267172513291833	tlh
Tael Singapore (Malaysia)	1 tls	≈	37.7993641666667	g	1 g	≈	0.0264554714621853	tls
Tael Taiwan	1 tlt	=	37.5	g	1 g	≈	0.0266666666666667	tlt
Tola	1 tola	=	11.6638038	g	1 g	≈	0.0857353241830079	tola
Baht	1 baht	=	15.16	g	1 g	≈	0.0659630606860158	baht

### 15.2 Recommended Printer Settings

Printer		Balance	Balance / Printer				
Model	Char Set	Char Set	Baudrate	Bit / Parity	Stop Bits	Handshake	End of Line
<b>RS-P25/26/28</b>	IBM/DOS	IBM/DOS	9600	8/NO	1	Xon/Xoff	<CR><LF> 1)
<b>RS-P42/43/45</b>	IBM/DOS 1)	IBM/DOS	1200	8/NO	1	Xon/Xoff	<CR><LF> 1)

1) Printer settings not available.

## 16 Index

### A

AC operation	16
Adjustment	18, 28, 28
Advanced menu	24
Advanced Menu	28
Ambient conditions	15
Appendix	91
Application "Check Weighing"	40
Application "Density"	51
Application "Diagnostics"	30, 60
Application "Division Factor Weighing"	49
Application "Multiplication Factor Weighing"	47
Application "Percent Weighing"	38
Application "Piece Counting"	36
Application "Routine Test"	57
Application "Statistics"	43
Application "Totaling"	45
Application "Weighing"	21
Application icons	11
Assign Application	30
Auto print	33
Automatic adjustment	18
Automatic shutoff	29
Automatic zero setting	30
Autozero	30

### B

Backlight	30
Balance history	63
Balance information	65
Basic menu	24, 26
Battery operation	16
Baudrate	34
Beep	27, 27
Bit/Parity	34

### C

Calibration	18, 28
Calibration history	64
Cancel	26
Change settings	25, 25
Char Set	35
Check Weighing	40
Cleaning	72
Closing the menu	25
Control Limit	58
Conventions and symbols	7
Conversion table for weight units	91

### D

Data communication format	33
Date	26
Date format	28
Delivery inspection	13

Density	51
Density kit	51
Density table for distilled water	55
Density table for ethanol	56
Diagnose	30
Diagnostics	60
Diagnostics application	30
Display	32
Display panel	11
Display test	61
Disposal	8
Distilled Water	55
Division Factor Weighing	49
Draft Shield	13, 72

### E

End of Line	35
Environment	28
Error messages	70
ethanol	56
External weight	19

### F

FACT	18, 28, 28
Factor Weighing	47, 49
Firmware update	69
Fully automatic adjustment	18, 28
Function PC-Direct	67

### G

Good Weighing Practice	57
GWP	57, 58

### H

Handshake	35
Header	32
Host	32

### I

Icons	11
Input principle	25
Installing the components	13
Interface menu	24, 31, 31
Interface MT-SICS commands and functions	73
Interface RS232C	31, 73
Internal weight	18
Interval	35
Introduction	7

### K

Key assign	30
Key beep	27
Key functions	10
Key test	62

### L

Leveling the balance	15
Line feed	33

Liquid	51	Service date reset	31
Liquids	53	Service icon	31
Location	15	Service provider information	66
<hr/>			
<b>M</b>		Service reminder	31
Main Menu	26	Setting up the balance	13
Manual adjustment with external weight	19	Shutoff	21, 29
Manual adjustment with internal weight	18	Signature line	32
Menu	24, 26	Single	32
Menu Advanced	24, 28	Sinker	51, 53
Menu Basic	24, 26	Software update	69
Menu Interface	24, 31, 31	Solids	51
Menu operation	25	SOP	58
Menu protection	26	Spare parts	89
Menu topic	25, 25, 26	Stability beep	27
Motor test	63	Startup	21, 29
MT-SICS interface commands and functions	73	Statistics	43
Multiplication Factor Weighing	47	Status icons	11
<hr/>			
<b>N</b>		Status messages	70
Net	22	Stop bit	34
Numerical values	25	Submenu	25
<hr/>			
<b>O</b>		Switching the balance on and off	21
Operation keys	10	Switching weight units	22
<hr/>			
<b>P</b>		Symbols and conventions	7
PC-DIR	31	<hr/>	
PC-Direct	67	<b>T</b>	
Percent Weighing	38	Taring	22
Performing a simple weighing	22	Technical data general	76
Piece Counting	36	Technical data model-specific	76
Power supply	16	Time	26
Print	23	Time format	29
Printer	31	Topic	25, 25, 26
Printer Settings	91	Totaling	45
Protect	26	Transmit data	23
Protocol trigger	28	Transporting the balance	17
<hr/>			
<b>Q</b>		<b>U</b>	
Quickstart	21, 29	Unit	27, 27
<hr/>			
<b>R</b>		Unpacking	13
Recall	23, 29	<hr/>	
Repeatability test	60	<b>W</b>	
Reset	27	Warning Limit	58
Routine Test	57	Weighing below the balance	17
RS232C interface	31, 73	Weighing made simple	21
<hr/>			
<b>S</b>		Weighing-in aid	23
Safety precautions	8	Weight unit	22, 27, 27, 91
Saving settings	25	<hr/>	
Select menu	25	<b>Z</b>	
Select menu topic	25	Zero print	33
Selecting the location	15	Zero range	30
Service	31, 31, 72	Zero setting	22
		Zeroing	30





## **GWP® – Good Weighing Practice™**

The global weighing guideline GWP® reduces risks associated with your weighing processes and helps to

- choose the appropriate balance
- reduce costs by optimizing testing procedures
- comply with the most common regulatory requirements

► [www.mt.com/GWP](http://www.mt.com/GWP)

[www.mt.com/jewelry](http://www.mt.com/jewelry)

For more information

**Mettler-Toledo AG, Laboratory & Weighing Technologies**

CH-8606 Greifensee, Switzerland

Tel. +41 (0)44 944 22 11

Fax +41 (0)44 944 30 60

[www.mt.com](http://www.mt.com)

Subject to technical changes.

© Mettler-Toledo AG 02/2011

11781452 2.12



\* 1 1 7 8 1 4 5 2 \*